iJiNUS
GROUPE CLAIRE

LOG04V4



Autonomous logger

User guide

IJINUS - 25 ZA de Kervidanou 3, 29300 MELLAC - France – SAV / After-sales service : +33 2 98 09 03 32 / sav@ijinus.fr

User guide: Version 06

Publication date 07/2026

Documentation valid from Avelour software version 7.5.1

Table of Contents

1. Document information 8
1.1. Background 8
1.2. Symbols used 8

2. Safety 9
2.1. General instructions 9
2.2. Note for users in Canada 9

3. Product marking information 10

4. Product description 11
4.1. Principle of operation 11
4.2. Description 12
4.3. Technical specifications 13
4.3.1. Data logger 13
4.3.2. Dimensions 14
4.3.3. M12 8-pin connector 15

5. Commissioning 16
5.1. Logger 16
5.1.1. Inserting the SIM card 16
Releasing electrical charges 16
Inserting a SIM card 16
5.2. Assembling the modem 2G / 4G kit 17
5.3. Recommendations for use and measurement 18
5.3.1. OPTOD sensor 18
5.3.2. NTU sensor 18
5.3.3. PHEHT sensor 19
5.3.4. C4E sensor 19
5.3.5. Oxydo reduction potential sensor 19
5.3.6. Capteur CTZ 19

6. Power supply 21
6.1. Using a mains power supply 21
6.2. Using a power pack 21

7. Connections 22
7.1. Wiring 22
7.1.1. Flow meter wiring in Modbus protocol 22
ABB Aqua master 4 23

ARAD - Octave 23
HENDLESS+HAUSER - Promag W 800 24
FUJI ELECTRIC - M5000 25
Krohne Waterflux 3070 26
SIEMENS - MAG8000 26
7.1.2. Physical-chemical sensors 27

8. Installation 28
8.1. Recommendations for Outdoor Installation 28
8.2. Installing a clamp 28
8.3. Installation with mounting kit 29
8.3.1. Installing a remote antenna 30

9. Configuration on Avelour 32
9.1. Equipment required 32
9.2. Installing the Avelour software 32
9.3. Connecting to a logger 32
9.4. Protect the logger using a password 35
9.4.1. Activation 35
9.4.2. Password Format 36
9.4.3. Forgotten password 36
9.5. General configuration information 37
9.6. Configuring a measurement recording 37
9.6.1. SurfaceFLO / Sommer SQ-R + Modbus 37
Principle 37
Configuration 37
Mapping table between DataID, channel & data 40
9.6.2. Mainstream Mainprobe : Doppler velocity sensor 42
Configuration 42
Overview and configuration saving 42
Mapping table between DataID, channel & data 42
9.6.3. Intelligent low-power Doppler measurement (Ubertone sensor) 44
Principle 44
Configuration 44
Mapping table between DataID, channel & data 47
9.6.4. Water height measurement: Low-profile Doppler (IAVL sensor) 49
Principle 49
Configuration 49
Mapping table between DataID, channel & data 53
9.6.5. Doppler velocity measurement (Nivus sensor) 55
Principle 55
Configuration 55
9.6.6. Doppler velocity and overflow measurement (Nivus sensor) 57
Principle 57
Configuration 57
9.6.7. Flow measurement: Doppler speed + built-in piezoresistive height (Nivus sensor) 59
Principle 59
Configuration 59
Combined Doppler speed/piezoresistive height sensor 59
9.6.8. Physical-chemical measurement 62
Principle 62

Configuration 62
Mapping table between DataID, channel & data 67
9.6.9. Conductivity measurement (B&C sensor) 70
Principle 70
Configuration 70
9.6.10. Measurement using an ISCO signature flow meter 72
Principle 72
Configuration 72
Mapping table between DataID, channel & data 73
9.6.11. Configure a wired modbus display on push-button 76
Operation 76
Display configuration 76
Configuration summary 76
9.6.12. Wired overflow detector 77
Principle 77
Configuration 77
9.6.13. Modbus master 80
Principle 80
Configuration 80
9.6.14. Measurement via DI/CO input 83
Principle 83
Configuration 83
Mapping table between DataID, channel & data 83
9.6.15. Modbus flow meter 85
Principle 85
Flowmeter wiring 85
Configuration 85
9.6.16. Measurement using the Modbus protocol : Slave mode 94
Principle 94
Settings 94
9.6.17. Recording of bucket toggles 96
Principle 96
Configuration 96
Configuration summary 96
Recording of bucket toggles 96
9.6.18. Cumulative Rainfall 98
Principle 98
Configuration 98
Rain gauge configuration 98
Mapping table between DataID, channel & data 99
9.6.19. Measurement for pump station management 100
Principle 100
Configuration 101
Mapping table between DataID, channel & data 102
9.6.20. Flow measurement using a 100 Hz velocity counter 104
Principle 104
Configuration 104
Mapping table between DataID, channel & data 106
9.7. Configuring the sending data 108
9.7.1. Technologies used 108
9.7.2. Signal quality: Mobile Signal Strength Value 109
9.7.3. Configuring the modem of the communication card 109
Technology to use 110
PIN code 110
APN 111
Priority operator (Multi-operator SIM) 111

Program modem 112
9.7.4. Check network quality: Modem diagnostics 112
9.7.5. Data sending in FTP(s) 115
9.7.6. Data sending in Http(s) 117
Configuration 117
9.7.7. Data sending in MQTT(s) 120
Principle 120
Message format 120
Activation 120
Configuration 121
Quality of Service (advanced setting) 121
Format Almaviva 121
Topic (advanced setting) 122
9.7.8. Advanced internet connection settings 123
PPP 123
SNTP 123
Custom DNS server 123
9.7.9. Certificate management 124
Generalities 124
Managing certificate 124
9.7.10. Data sending via SMS 126
9.7.11. Data sending in LoRaWAN 128
Transmission cycle 128
Login information 128
Test data transmission 128
Advanced settings 129
Expert mode 129
Integration of a logger on Orange Live objects 129
Integration of a logger on WIOTYS 130
Integration of a logger on THE THINGS 130
9.7.12. Configure an alarm 132
9.7.13. Sending an alert SMS 132
9.8. Test data transmission before commissioning 133
9.8.1. Objective 133
9.8.2. Test procedure 133
9.8.3. Troubleshooting 133
9.9. Power supply configuration 134
9.9.1. Lithium battery 134
9.9.2. Lead-acid battery 135
9.10. Set time zone 136
9.11. Pairing one or more loggers 136
9.12. Check the status of data recording and transmission 137
9.13. Save the configuration to the logger 138
9.14. Visualize measured values in real time 139
9.15. Stop a recording in progress 140
9.16. Disconnect from the logger 140
9.17. Managing a configuration 140
9.17.1. View a configuration file 140
9.17.2. Archive a file 140
9.17.3. Create a configuration template 141

9.17.4. Apply a configuration template 142

10. Data management on Avelour 143
10.1. Retrieving saved data 143
10.2. Retrieve data from auxiliary memory 144
10.3. Create a new calculated value 146
10.4. Data graph 147
10.4.1. Display tools on Avelour 147
10.4.2. Show data graph 147
10.4.3. Customize the graph display 148
10.4.4. Hide the display of data on the graph 149
10.4.5. Display values in table form 149
10.5. Export retrieved data 151
10.6. Delete data recorded on the logger 151

11. Maintenance 153
11.1. Replacing the battery 153
11.2. Firmware update 155
11.3. Remote firmware update 156
11.4. Reset the logger (factory settings) 157
11.4.1. Wiji reset 157
11.4.2. Manual reset 158
11.5. Replacing the cartridge on a PHEHET sensor 158
11.6. Cleaning 158
11.6.1. OPTOD sensor 158
11.6.2. NTU sensor 159
11.6.3. PHEHT sensor 159
11.6.4. Redox annulaire 159
11.6.5. C4E sensor 159
11.6.6. CTZ sensor 159

12. Storage 160
12.1. Sensor Storage 160
12.1.1. OPTOD sensor 160
12.1.2. PHEHT sensor 160
12.1.3. Redox annulaire sensor 160
12.1.4. NTU sensor 160
12.1.5. C4E sensor 160
12.1.6. CTZ sensor 160

Chapitre 1. Document information

1.1. Background

This user guide contains all the information required to install, connect and commission the unit, as well as important notes concerning maintenance. It is therefore essential to read it before commissioning any Ijinus equipment.

1.2. Symbols used



This symbol indicates a situation or use that may result in damage, fault or equipment malfunction.



This symbol indicates additional information useful for the understanding and correct use of the equipment.



This symbol indicates a prerequisite for performing a task.

Chapter 2. Safety

2.1. General instructions

This document presents a number of operations and programming to be performed on a data logger, a sensor or an accessory supplied by Ijinus. These operations must only be performed by personnel qualified to use Ijinus products. The information provided in this user guide only ensures operational safety if the equipment is used correctly. Performing any work on the device requires the use of appropriate personal protective equipment. Below we have provided a non-exhaustive list of recommendations to apply to ensure the safety of Ijinus data logger users:

- Only use batteries specified by Ijinus.
- Risk of fire or burns with lithium batteries: do not short-circuit, recharge, puncture, incinerate, crush, immerse, fully discharge or expose the batteries supplied by Ijinus to temperatures above the operating temperature range.
- Do not shake the sensor.
- Do not physically modify the sensor.
- Do not clean the device with an aggressive product, particularly Acetone and similar.
- The device contains components that may be damaged or destroyed by electrostatic discharge. Release any electrostatic charge from your body before opening the device and handling it. To do this, touch a grounded metal surface. Ijinus assumes no liability for damage resulting from incorrect or non-compliant use.

2.2. Note for users in Canada

This device complies with Industry Canada's RSS for license-exempt radio equipment.

The operation is authorized subject to the following two conditions: (1) it must not cause interference, and (2) the user of the device must be prepared to accept any radio interference received, even if this interference is likely to compromise the operation of the device.

In accordance with Industry Canada regulations, this radio transmitter may be operated with an antenna of a type and maximum gain (or less) approved for the transmitter by Industry Canada.

To reduce the risk of radio interference to other users, the type of antenna and its gain must be chosen so that the equivalent isotropically radiated power (e.i.r.p.) does not exceed the intensity required to establish satisfactory communication.

This device complies with the RF personal exposure requirements defined by Industry Canada. This device must be installed so as to provide a separation distance of at least 20 cm from the user, and must not be installed near or used in conjunction with any other antenna or transmitter.

If the antenna is removable (RSS-GEN): This device has been designed to work with the antennas listed below, with a maximum gain of 0 dBi. Antennas not included in this list, or with a gain exceeding 0 dBi, are strictly forbidden for use with this device. The required antenna impedance is 50 Ω. List of acceptable antennae:

- IJINUS
- B0E type

Chapter 3. Product marking information



The CE mark indicates that the product complies with current European directives.



Consult the user manual before using the product.



Do not dispose of this product in household waste. The product must be sent to a specific collection point, or collected by an organization that will ensure its further processing.



Direct current

Meaning of symbols

Chapter 4. Product description

4.1. Principle of operation

Ijinus loggers are designed to be standalone units powered by a lithium battery. They log data transmitted by the equipment to which they are connected. A mobile programming unit (M0C00001) or a Wiji USB dongle (WIJIKEY-8) can be used to connect to the logger by radio (Wiji protocol), configure it and retrieve data locally. Depending on the logger model, it can be fitted with a modem, enabling data to be transmitted automatically and wirelessly to our Web platform www.ijitrack.com, or to a client server.



4.2. Description

The logger is powered by an internal battery. The logger housing has an IP68 waterproof rating (can be submerged in 10 meters of water for 30 days).

A radio access point, also called a programming antenna, must be used to program the logger. This access point can also be used for local, wireless (within a maximum of a few dozen meters between the logger and the access point connected to the USB port of a computer) download of data measured by the built-in sensor, or connected to the logger via the M12 8-pin connector (**A**).





LOG04 data logger



3.6 V 34 Ah non-rechargeable lithium battery



Programming antenna



Remote antenna (optional)



Mounting kit: 2 x mounting plates + 1 x bracket + 4 nuts and bolts



Connection cable (if required)

4.3. Technical specifications

4.3.1. Data logger

Features	**LOG04V4-82-LTE** (868 MHz) - **LOG04V4-92-LTE** (915 MHz)
Data logger	500,000 measures
Concentrator	Yes
Inputs	1 Voltage input (5 V...30 V) 1 Modbus input (if not used as output) 2 Digital inputs or 100 Hz metering
Outputs	HF radio (868 or 915 MHz) 2G / LTE-M / NB-IoT 1 Voltage output (5V-18V on internal battery or Vin switch) 1 Open Collector Output 1 Modbus output (if not used as input)
Radio communication	100 meters in open field (Wiji protocol)
Radio / mobile antenna	Internal or external radio – External mobile
Temperature range	-40°C to 85°C
Data logger material	PA12
Ingress protection	IP68: 1 bar for 30 days (only if using Ijinus mounting kit; P/N: H0T00053 or H0T00060)
Power supply	Battery: 3.6 V - 34 Ah
Configuration	Wireless Programming Kit (PN: M0C00001) integrating AVELOUR software
Atex zone 2 certification 	II 3G Ex ic ec IIB T4 Gc Ambient temp: -20°C to 60°C
Certifications	CE - FC : SE6A002-A0102 / IC: 10983A-A002-A0102

4.3.2. Dimensions



4.3.3. M12 8-pin connector

Wiring



Female



Male

Cable color	White ○	Brown ●	Green ●	Yellow ●	Grey ●	Pink ●	Blue ●	Red ●
8-pin connector: No.	1	2	3	4	5	6	7	8
Name	Vin	GND	Vout	Input OR Output	Input OR Output	Input	Input	Output Open-Drain
Features	(5 V - 30 V)	Ground	5 V - 18 V * (internal battery) or Switch Vout = Vin	RS485-H	RS485-L	On/Off 2 / Metering 1 100Hz	On/Off 2 / Metering 2 100Hz	Contact Grounding
Type	Power supply input		Power supply output	Modbus	Modbus	Digital	Digital	Open drain (1 A / 30 V)

* Maximum 1.8 W on V_{out} if the connected sensor is powered by the internal battery (voltage adjustable via software).

Chapter 5. Commissioning

5.1. Logger

If the logger does not have a communication PCB, there is no need to open the housing as the internal battery is already connected to the PCB. The logger is therefore operational immediately.

Ijinus loggers do not require activation, as they listen for a radio connection request from a radio access point or another logger every 10 seconds.

If the logger has a communication PCB (LTE option, for example), then the SIM card must be inserted in its holder, see paragraph *Inserting the SIM card*.

5.1.1. Inserting the SIM card

Loggers with a communication PCB require a SIM card to operate. The SIM card holder is located on the communication PCB.

Releasing electrical charges

Our sensors and loggers contain components that can be damaged by electrostatic discharge.



It is imperative to release any static electricity from your body before opening the product.

To do so:

- Touch a grounded surface such as an electrical cabinet enclosure

Inserting a SIM card



Avoid leaving the logger open for too long (just a few minutes), because if the desiccant bag absorbs too much moisture, it will no longer be effective and will turn green.



Removing the cover can be difficult due to the gasket. The cover antenna is connected to the circuit board, so to avoid pulling out the circuit board when opening the logger, we strongly advise you to open the logger as follows:

- Partially unscrew the clamping ring (**A**) (approx. 2 turns).
- Pull on the cover until it is partially extracted, secured by the clamping ring.
- Unscrew the clamping ring completely to fully remove the cover.
- Insert the SIM card into the SIM card holder, ensuring that it is inserted with the beveled side to the top right.
- Check the color of the desiccant bags and replace them if they are green.



- Replace the cover as far as it will go, taking care to fit the insertion notch into the coded hole (**B**).





- Retighten the clamping ring (**A**).

5.2. Assembling the modem 2G / 4G kit

Unscrew the clamping ring and remove the cover	Put the communication card	Replace the desiccant sachet with a new one.







Insert the male connector (A) of the antenna cable into the hole (B) and connect it to the card via the female connector (C)	**Replace the cover, pushing it all the way in, taking care to ensure that the insertion notch is correctly aligned with the pin (D)**	**Screw the antenna to the cover**







5.3. Recommendations for use and measurement

5.3.1. OPTOD sensor

Operating temperature: 0°C to 50°C

Compensation of temperature effective on 0-40°C

Warning ! The membrane is vulnerable to:

- chemicals (organic solvents, acids, peroxide),
- mechanical treatments (impact, abrasion, tearing).

For measurement,

- Eliminate bubbles trapped under the membrane. Presence of chlorine will distort the measure (overestimation of dissolved oxygen level).
- During the installation of the sensor in measurement environment, wait for sensor's temperature stabilization before measure processing.

5.3.2. NTU sensor

Operating temperature: 0°C to 50°C



Warning ! The optical windows are vulnerable to:

- chemicals (organic solvents, acids, peroxide),
- mechanical treatments (impact, abrasion, tearing).

While in use, the sensor must not make contact with walls or bottom of the jar. A minimal clearance of 2/3 cm is recommended (depending on the environment concentration). Bubbles on optical parts can interfere with the measurement. On environment change, wait sensor's temperature stabilization before proceeding with measurement.

In the range of 0 to 20 NTU and in case of sensor the saturation (9999 value), it is recommended to use the protection strainer to avoid various interferences like edge effects, solar radiation.

5.3.3. PHEHT sensor

Operating temperature: 0°C to 50°C



The glass electrode is vulnerable to:

- chemicals (organic solvents, acids and strong bases, peroxide, hydrocarbons),
- mechanical treatments (impacts). The redox potential electrode is sensitive to sulphide adsorption on platinum.

- During the installation of the sensor in measurement environment, wait for sensor's temperature stabilization before measure processing.

5.3.4. C4E sensor

Operating temperature: 0°C to 50°C



The 4 electrodes are sensitive to deposits (some fat, hydrocarbons, biofilm, mud)

- During the introduction of sensor in the measurement environment, wait sensor's temperature stabilization before proceeding with measurement.

5.3.5. Oxydo reduction potential sensor

Operating temperature: 0°C to 50°C

The electrode used to measure the redox potential is sensitive to sulphides, which are adsorbed onto the platinum.

- During the installation of the sensor in measurement environment, wait for sensor's temperature stabilization before measure processing.

5.3.6. Capteur CTZ

Operating temperature: 0°C to 50°C



Measurement technology that is ‘unaffected’ by fouling. However, ensure that the loop is not blocked..

- During the installation of the sensor in measurement environment, wait for sensor’s temperature stabilization before measure processing.

The sensor is not suitable for measurements in the lowest ranges

Chapter 6. Power supply

6.1. Using a mains power supply

Ijinus loggers can be powered from an external mains supply. The voltage delivered to the logger must be between 8 V and 30 V.



You must use a transformer (e.g. 220 V / 24 V) that is correctly grounded. In the absence of a ground connection, several malfunctions may occur (metering problems, measurement disturbances, etc.) due to disturbances caused by the mains power supply.

- To configure the logger, please refer to paragraph *Power supply configuration*.

6.2. Using a power pack

Two main types of batteries are available from Ijinus:

- Rechargeable lead-acid battery.
- Non-rechargeable lithium battery.

Lead-acid batteries have a voltage of 12 V.

Two types of lithium batteries are available: 10.8 V and 14.4 V.



Do not use a 14.4 V battery on a sensor other than the Nivus Doppler.

Applying a voltage above 13 V to an Aqualabo sensor will disable the sensor.

- To configure the logger, please refer to paragraph *Power supply configuration*.

Chapter 7. Connections

7.1. Wiring

Wiring



Female



Male

Cable color	White ○	Brown ●	Green ●	Yellow ●	Grey ●	Pink ●	Blue ●	Red ●
8-pin connector: No.	1	2	3	4	5	6	7	8
Name	Vin	GND	Vout	Input OR Output	Input OR Output	Input	Input	Output Open-Drain
Features	(5V to 30V)	Ground	5V to 18V * (internal battery) or Switch Vout = Vin	RS485-H	RS485-L	Current 1	Current 2	Contact Grounding
Type	Power supply input		Power supply output	Modbus	Modbus	4 - 20 mA	4 - 20 mA	Open drain (1A/30V)

* Maximum 1.8 W on V_{out} if the connected sensor is powered by the internal battery (voltage adjustable via software)

7.1.1. Flow meter wiring in Modbus protocol

For the flowmeter to operate correctly in the Modbus protocol of communication (see paragraph *Measurement using the Modbus protocol : Slave mode*, the ground must be wired.

ABB Aqua master 4



External side view connector

Flowmeter connector	Color	Function	M12 12 pts connector
A	Grey	RS485 L	8
B	Yellow	RS485 H	6
C	-	/	-
D	-	/	-
E	-	/	-
F	-	/	-
G	Brown	GND	1

ARAD - Octave



Câbles

	Fil	Fonction
ModBus	Bleu	D0/A/Tx+
	Blanc/Bleu	D1/B/Tx-
	Orange	5-24Vdc
	Blanc/Orange	Ground

Impulsion*	Rouge	Sortie impulsion
	Noir	Ground

MAG8000	Octave wire cable	IJINUS wire cable	Function	Pts connecteur M12 12 pts
Tx+	Blue	Yellow	RS485 H	4

MAG8000	Octave wire cable	IJINUS wire cable	Function	Pts connecteur M12 12 pts
Tx-	Blue/White	Grey	RS485 L	5
GND	Black	Brown	GND	2

HENDLESS+HAUSER - Promag W 800





Broche	Fonction
A	PSO1+ (sortie impulsion/état 1+)
B	COM (potentiel de référence sorties impulsion/état)
C	NC (non connectée)
D	Terre
E	RS485_+ (Modbus B)
F	RS485_- (Modbus A)
G	PSO3+ (sortie impulsion/état 3+)
H	PSO2+ (sortie impulsion/état 2+)
J	NC (non connectée)
K	NC (non connectée)

MAG8000	IJINUS wire color	Fonction	M12 12 pts connector pts
E	Yellow	RS485 H	4
F	Grey	RS485 L	5
B	Brown	GND	2

FUJI ELECTRIC - M5000



Input/Output	Description	Terminal
Output 1	Passive maximum 30V DC, 20 mA Maximum frequency 100 Hz	OUT1 (+) and (–)
Output 2	Passive maximum 30V DC, 20 mA Maximum frequency 100 Hz	OUT2 (+) and (–)
Output 3	Passive maximum 30V DC, 20 mA Maximum frequency 100 Hz	OUT3 (+) and (–)
Output 4	Passive maximum 30V DC, 20 mA Maximum frequency 100 Hz Can be used with digital input as an ADE interface.	OUT4 (+) and (–)
RS232	Modbus RTU	RxD, TxD, GND
IN	Digital input 3…35V DC	IN (+) and (–)
M-Bus [1]	M-Bus interface	No polarity
Optional Modbus RS485 [2]	Modbus Interface Powered external 5…32V DC Optional internal by battery	GND, B-, A+, 12V

Flowmeter connector	Color	Function	M12 12 pts connector
A+	Yellow	RS485 H	4
B-	Grey	RS485 L	5
GND	Brown	GND	2

Krohne Waterflux 3070



External side view connector

Flowmeter connector	wire Color	Function	M12 12 pts connector
1	Grey	RS485 L	8
2	Yellow	RS485 H	6
3	NC	/	NC
4	Brown	GND	1

SIEMENS - MAG8000



D+ : RS485 High (A) – IJINUS fil jaune
D- : RS485 Low (B) - IJINUS fil gris
COM : GND (fonctionne sans câblage de la masse) - IJINUS fil marron

Flowmeter connector	Color	Function	M12 12 pts connector
D+	Yellow	RS485 H	4
D-	Grey	RS485 L	5
GND	Brown	GND	2

7.1.2. Physical-chemical sensors

Wiring



Female

Cable color	Black	Red	White	Green
8-pin connector	2	3	4	5
Name	GND	V+	Modbus	Modbus
Features	Masse	Alimentation	RS485 H	RS485 L

Chapter 8. Installation

8.1. Recommendations for Outdoor Installation

It is recommended to avoid installing the unit in a location directly exposed to sunligh

Installing the logger in the shade will help limit the internal temperature rise, which can affect the battery life. This will protect the logger from excessive temperature fluctuations, allowing for longer-term use.

8.2. Installing a clamp

To fit the Ijinus clamp:

- Position the clamp so that the Ijinus logo is aligned with the logger logo.
- To remove the clamp, insert a screwdriver into the notch (A) and pry the clamp loose.



8.3. Installation with mounting kit



Kit contents: 2 x mounting plates + 1 x bracket + 4 nuts and bolts



Assembled kit version 1



Assembled kit version 2



Example of installation with a mounting plate



Example of installation with two mounting plates



Mounting plate dimensions

8.3.1. Installing a remote antenna

The use of a remote antenna is useful if the logger is installed in a manhole with a buffer. In this case, connection to the logger may not be possible.

You must use an Ijinus remote antenna. Three lengths are available as standard: 1, 3 or 5m. In exceptional cases, a length of 10m may be proposed.

The antennas are suitable for sewerage network applications with a thick cable and reinforced sealing

- Connect the antenna to the sensor by screwing it **firmly** by hand and all the way to ensure a good seal.
- Identify the best conditions for installing the antenna, particularly the drilling direction for the best communication quality. A positioning and data transmission test is available in the Avelour software. You must do this test before and after installation (cover closed in the case of a manhole).
- Drill so that the antenna is outside the base area.



- Test positioning and data transmission using the Avelour software. This test should be carried out before and after installation (closed plug in the case of a manhole).



Drilling into the manhole



Inserting antenna under the base

Chapter 9. Configuration on Avelour

9.1. Equipment required

- Avelour software version 7.1 or later.
- A Wiji radio antenna in “long range” or “USB device” format.

9.2. Installing the Avelour software

The Avelour software can be downloaded from the Ijinus website (www.ijinus.com) in the “Download” section.

- To install it in the background, open the Avelour software via the command line interface using space + /S after its name.

Example: `Setup_Avelour_7.1.2-Signed.exe /S`

9.3. Connecting to a logger

- Connect the Wiji radio access point and its antenna (or the Wiji USB device) to your computer’s USB port.

  If the Wiji USB device is not detected:

  - Remove the USB device from the port, reboot the PC and reinsert the device.
  - If the device is still not detected, remove it and reinstall the drivers.

    `C:\Program Files (x86)\Ijinus\Avelour_7.1.2\Driver`

  - Restart the PC and reinsert the USB device.
- Position your Wiji antenna at least one meter from the logger.
- Open the Avelour software.
- Open the logger selection window by clicking on “Connect to a wireless device”.



- Select the logger identified by its serial number (refer to its nameplate) and click “OK”.



Location of serial number



-> The logger configuration window opens.



Configuration window for logger S/N: IJA0102-00002718

-> A configuration file is automatically created.

-> A folder is created in the following directory: `C:\ProgramData\Ijinus\Avelour_Main_7.1.2\SavedSensors\IJA0102-00002718`



Configuration file in the saved data browser.

9.4. Protect the logger using a password

9.4.1. Activation

To activate the protection, the latest firmware version and at least version 7.3 of Avelour must be installed.

By default, password protection is not active.

To activate it:

- In the system options, click on **Activate** and enter the following password using the required format (see *Password Format* paragraph).





Password input and confirmation window



-> A temporary password is saved in Avelour for the current session and as long as Avelour is not closed, the password is not requested again.

-> After 3 failed attempts, you must redo the connection process from the start.

-> The Password is required to review the configurations that were generated while the password was activated (presence of a padlock).



Password-locked configuration files

9.4.2. Password Format

The rules for the password format are as follows:

- Maximum length of 64 characters.
- Characters NOT allowed: **Space**, **accent** and **cedilla** .
- Minimum length: 1 character.
- No restrictions on the combination of characters.

9.4.3. Forgotten password

In case of a forgotten password:

- Manually reset the logger. (see *Manual reset*).

A manual reset deletes all settings and data files stored on the logger.

9.5. General configuration information

Editing the general information parameters allows you to input information concerning the identification of the logger, the measurement point, the date and any comments.

- Click on "Edit" and enter the required information if necessary.





General information editing window

9.6. Configuring a measurement recording

9.6.1. SurfaceFLO / Sommer SQ-R + Modbus

Principle

The radar flowmeter automatically calculates the flow rate based on the velocity measured by the surface velocity radar, the head measured by a head sensor, and the hydraulic tables programmed for the specific site.

Configuration

To save the configuration to the recorder, a Wiji connection to the recorder must be established, see *Connecting to a logger*. Otherwise, the configuration can be saved to disk.

- Click on ⊕ to add a configuration template and select "SurfaceFLO / Sommer SQ-R + Modbus".

Prerequisite

Sensor Configuration Prerequisites (via Commander software)

Output setting :	Units :
Apply the 'Default Modbus Settings'	Speed = m/s | Decimal places = 3 Water level = mm | Decimal places = 0 Flow rate = m³/s | Decimal places = 6

Measurement period

- Select the interval between measurements from the list. By default, a measurement will be taken every 15 minutes.
- Select **Stop** to force a measurement.

Modbus configuration

Modbus settings can be accessed by enabling advanced settings.



Modbus parameters by default

Data

Several units can be used to express **flow rate** :

- The default unit is m³/s
- It is also possible to use the unit m³/h

The 'm' (meter) unit allows water heights of up to 2,147,483 m to be calculated. With the 'mm' unit, the maximum value is 32,000 mm (i.e. 32 m).

Changing the unit will also change the dataID (this may affect data integration in data monitoring systems (SCADA) other than Ijitrack).



Volume

Several units can be used to express **volume** :

- The default unit is m³ with a resolution of 0.001 m³ (maximum possible value 2,147,483 m³)
- It is also possible to use the litre unit (maximum possible value: 2,147,483,600 litres, i.e. 2,147,483 m³)
- Finally, it is possible to use the unit m³ with a resolution of 1 m³ to obtain a maximum value of 2,147,483,600 m³

Changing the unit will also change the dataID (this may affect data integration in data monitoring systems (SCADA) other than Ijitrack).



Overview and configuration recording

- Check the settings by clicking on 'SEE OVERVIEW'.



- If the logger is connected, click on **Save configuration** to upload the configuration on the logger.



- If not connected, click on **Save on the disk** and the configuration can be uploaded later when connected to lthe logger.

Mapping table between DataID, channel & data

DataId	Channel	Data displayed	Units	Data Description	Data files
3	7	Debug (signed integer value)	mAh	Internal battery current consumption	*_diag.bin
4	0	Debug (Real value)	-	Quality (SNR)	*_sommer.bin
6	0	Voltage	V	Instantaneous internal battery voltage (Res. 0.05 V)	*_diag.bin
6	1	Voltage	V	Minimum internal battery voltage reached (Res. 0.05 V)	*_diag.bin
6	2	Voltage	V	Instantaneous external battery voltage (Res. 0.05 V)	*_extbat.bin, *_extvolt.bin
15	9	Water height	mm	Water height in mm	*_sommer.bin
17	0	GSM signal Power	dBm	GSM signal power	*_diag.bin
19	0	Date	-	POSIX time	Données asynchrones
24	5	Velocity	mm/s	Measured velocity	*_sommer.bin
25	0	Doppler signal quality	%	Doppler signal quality (Opposite direction content)	*_sommer.bin
34	4	Flow	m³/s	Flow rate in m³/s	*_sommer.bin
39	16	Volume	m³	Infinite volume accumulation in m³ (Res. 0.001)	*_sommer.bin
39	17	Volume	m³	Periodical volume in m³ (Res. 0.001)	*_sommer_volcount.bin
47	9	Water height	m	Water height in m	*_sommer.bin
48	4	Flow	m³/h	Flow rate in m³/h	*_sommer.bin
49	16	Volume	L	Infinite volume accumulation in Liter	*_sommer.bin
49	17	Volume	L	Periodical volume in Liter	*_sommer_volcount.bin
57	16	Volume	m³	Infinite volume accumulation in m³ (Res. 1)	*_sommer.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
57	17	Volume	m³	Periodical volume in m³ (Res. 1)	*_sommer_vol-count.bin

9.6.2. Mainstream Mainprobe : Doppler velocity sensor

Configuration

- Click on the ⊕ button to add a measurement configuration and select "Mainstream Mainprobe : Doppler velocity sensor".



Mesurement failure : Allows the speed value to be overridden if the signal quality is too low (> 5 %)

- Don't replace velocity
- repalce velocity with previous value
- replace by specific value : Between -8888 and 9999 , -8888 is a special value which doesn't allow the volume calculation based on this speed.

Overview and configuration saving

- Check the settings by clicking on 'SEE OVERVIEW'.



- If the logger is connected, click on **Save configuration** to upload the configuration on the logger.
- If not connected, click on **Save on the disk** and the configuration can be uploaded later when connected to lthe logger.

Mapping table between DataID, channel & data

Datatype	Channel	Displayed data	Units	Description	Data files
3	7	Debug (signed integer value)	mAh	Internal battery current consumption	*_diag.bin
6	0	Voltage	V	Instantaneous internal battery voltage (Res. 0.05 V)	*_diag.bin

Datatype	Channel	Displayed data	Units	Description	Data files
6	1	Voltage	V	Minimum internal battery voltage reached (Res. 0.05 V)	*_diag.bin
12	1	Measure temperature	°C	Sensor temperature measurement (Res. 0.1°C)	*_mainstream.bin
17	0	GSM signal Power	dBm	GSM signal power	*_diag.bin
19	0	Date	-	POSIX time	Asynchronous data
24	0	Velocity	mm/s	Velocity	*_mainstream.bin
25	0	Doppler signal quality	%	Sensor quality (0-100)	*_mainstream.bin

9.6.3. Intelligent low-power Doppler measurement (Ubertone sensor)

Principle

The Ubertone sensor is a Doppler-effect velocity sensor. Placed in the opposite direction to the flow, its principle is to measure the velocities of bubbles and/or particles present in the water, assuming that they are moving at the same speed as the water. Ubertone technology measures the velocity of bubbles and/or particles in a 65° emission cone (relative to the horizontal), with a propagation angle of 10°. In less than a second, the sensor fires more than 1,000 ultrasonic beams at a frequency of 1 MHz.

The Doppler velocity sensor can be connected to an energy pack, which in turn is connected to the water level sensor, or powered directly by the internal battery. The height sensor needs to be configured, as it controls velocity measurement, height measurement, a number of calculations and data transmission.

Configuration

- Click ⊕ to add a measurement configuration and select “Intelligent low-power Doppler measurement".
- Select a measure period identical to that set for level measurement.



Operation in default configuration

In simple mode (default setting), the doppler is configured as follows:

- Whatever the threshold of usable echo quantity (Doppler quality channel 1), the sensor will propose a velocity value.
- For each velocity measurement, a global quality code (Doppler channel 0) is calculated, ranging from 0 to 4:
  - 4: best quality.
  - 2 or 3: the average value from the sensor (Channel 1) is not representative of the actual flow velocity. This configuration is most often encountered when the water level is low: less than 5 cm, i.e. less than 2 to 3 cm above

the sensor. In this case, since the average velocity (1) of the sensor is not representative, the Hydraulic indicator (noted at 3, i.e. V average / V max) cannot be used for typical values either.

- 0: sensor does not respond.

If the mean velocity (channel 0) is greater than 200 mm/s and the ratio between the standard deviation (channel 2) and its mean velocity is less than 0.25 (i.e. less than 25% variation), then the proposed velocity (i.e. channel 0 - the one used to calculate flow in the LNU) will be the mean velocity obtained from the sensor, and the sensor's overall quality code (Doppler quality channel (0)) will be equal to 4.

If the quality code is less than 4 (in this case 3 or 2), then the velocity (proposed in channel 0) will be derived from the maximum sensor velocity (channel 3) multiplied by 0.8 (multiplying factor).

Measure check

- Click  to view Ubertone sensor measurement results.

If the sensor cannot provide a reliable measurement, then Measurement quality = 1 and Velocity after processing = -9999 mm/s (default replacement value).

If the sensor does not respond, then Measurement quality=0 and Velocity= +9999 mm/s.



Typical values may differ from site to site. The two most important indicators are:

- global (4 = best, 1 = worst),
- Doppler SNR (20 = best, <10 poor).

The hydraulic indicator should only be interpreted if the global quality code is 4.

Channel	Measurement quality (0-4)	Typical values
Channel 1	EchoSnr: exploitable echo quantity - Water bubble/particle indicator (0-40 dB)	• 0 to 3 in air • 3 to 10 between air & water • from 10 to 40 in water (40 being strictly wastewater or multiple)
Channel 2	DopplerSnr: Doppler evaluation quality (0-20 dB)	• below 10: mediocre • from 10 to 16: good • from 16 to 20: excellent
Channel 3	Hydraulic indicator: ratio between average Ub Velocity and Max Ub Velocity (%)	• Under 70%: poor quality or special structure • between 70% and 90%: circular current
Channel 4	Flow direction: 0 or 1	• 1: Velocity > 0 • 0: Velocity < 0

Diagnostic

- Click  **Diagnostic** to view all the parameters measured by the Ubertone sensor.

Channel	Velocity after processing

Channel 1	Average Ub velocity
Channel 2	Standard deviation Velocity Ub
Channel 3	Max Ub velocity
Channel 4	Min Ub speed

If the collector is horizontal and at the bottom of the collector -> Pitch=Roll=90°.

These angles have no influence on the calculation, but are used to determine the position of the sensor. Their resolution to 1° also makes it impossible to measure the slope of the collector.

Measurement parameters (advanced settings)

- Click to display the following measurement parameters.



Threshold applied to quantity of exploitable echo : Usable echo quantity - Water bubble/particle indicator (0-40dB).

Coefficient applied to maximum velocity

Record temperature : The sensor is fitted with a temperature probe.

Replacement velocity value if measurement impossible : select a value

Expert mode

- If expert mode is enabled, click to display expert mode settings.



Paramétrage en mode expert

Fifo Memory (Advanced Setting)

By default, when the logger memory is full, data are deleted in chronological order of recording, from oldest to newest.

- Click to display advanced settings.
- If Fifo memory is disabled, change the maximum number of timestamps for the main memory (used for sending data via Internet) and the auxiliary memory (used for sending data via SMS) if necessary.



Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.

Mapping table between DataID, channel & data

DataId	Channel	Data displayed	Units	Data Description	Data files
3	7	Debug (signed integer value)	mAh	Internal battery current consumption	*_diag.bin
6	0	Voltage	V	Instantaneous internal battery voltage (Res. 0.05 V)	*_diag.bin
6	1	Voltage	V	Minimum internal battery voltage reached (Res. 0.05 V)	*_diag.bin
6	2	Voltage	V	Instantaneous external battery	*_extbat.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
				voltage (Res. 0.05 V)	
12	1	Measure temperature	°C	Sensor temperature measurement (Res. 0.1°C)	*_ubflowav.bin, *_diag-ubflowav.bin
17	0	GSM signal Power	dBm	GSM signal power	*_diag.bin
19	0	Date	-	POSIX time	Asynchronous data
24	0	Velocity	mm/s	Treated velocity	*_ubflowav.bin, *_diag-ubflowav.bin
24	1	Velocity	mm/s	Average raw velocity	*_ubflowav.bin, *_diag-ubflowav.bin
24	2	Velocity	mm/s	Standard deviation raw velocity	*_ubflowav.bin, *_diag-ubflowav.bin
24	3	Velocity	mm/s	Maximal raw velocity	*_ubflowav.bin, *_diag-ubflowav.bin
24	4	Velocity	mm/s	Minimal raw velocity	*_ubflowav.bin, *_diag-ubflowav.bin
25	0	Doppler signal quality	%	Sensor quality (0-4)	*_ubflowav.bin, *_diag-ubflowav.bin
25	1	Doppler signal quality	%	EchoSnr (0-40 dB)	*_ubflowav.bin, *_diag-ubflowav.bin
25	2	Doppler signal quality	%	DopplerSnr (0-20 dB)	*_ubflowav.bin, *_diag-ubflowav.bin
25	3	Doppler signal quality	%	Hydraulic indicator (%)	*_ubflowav.bin, *_diag-ubflowav.bin
25	4	Doppler signal quality	%	Flow direction (0 or 1)	*_ubflowav.bin, *_diag-ubflowav.bin
44	0	Angle	°	Roll angle (Res. 0.1°)	*_diag-ubflowav.bin
44	1	Angle	°	Pitch angle (Res. 0.1°)	*_diag-ubflowav.bin

9.6.4. Water height measurement: Low-profile Doppler (IAVL sensor)

Principle

The IAVL sensor measures the water level using a built-in piezoresistive sensor.

Configuration

Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger*.

- Click to add a measurement configuration and select “IAVL sensor: Low Profile Doppler measurement".

Piezoresistive water level



- Enter an **offset** on the measured height if the sensor is not placed at the bottom of the structure where we wish to measure the height

- Click calibration if necessary to adjust the value measured by the IAVL sensor with the actual height value **H**.



Doppler velocity



Velocity measurement only above a level threshold : Activated by default.

Level threshold : Threshold above which velocity measurement is active.

Correct the velocity in case of a measurement error : By the last valid value or By a specific value or No.

If By a specific value is selected: Define a **Corrective velocity**.

Velocity and diagnostics are null in case of a measurement error.

Consider the negative velocities as null : Activate if necessary.

Doppler diagnostics record : Activate if necessary.

3 quality indicators available: particle density, amount of useful signal, and flow direction homogeneity (unit: %)

Useful signal amplitude

This is a direct indication of the amount of amplification applied to the unprocessed return signal received.

- 0% means that the amplifier has been set to "10", i.e. at its maximum.
- 100% means no amplification was required.

Typically, the rate is between 40% and 75%, but a lower or even slightly higher value may simply indicate the conditions under which the device is operating. With this value, the aim is to observe a regular daily or event trend that remains consistent. If you start to observe a deterioration in this value, it probably indicates that silt, sediment or something else is beginning to accumulate on or in front of the sensor, affecting the measurement.

Particle density

Velocity measurement is based on the Doppler shift of the signal reflected by suspended particles and entrained air (bubbles) in the flow. However, reflections from other objects are also picked up, such as surface turbulence, eddy currents, stationary debris, a hanging rag upstream waving in the flow, etc... These reflections are not representative of velocity, so if they were used in processing where the unit determines average velocity, the result would be wrong. There is therefore an algorithm that eliminates these non-velocity-related components, before moving on to the weighted average process to determine the mean velocity.

As with the useful signal amplitude, the trend should be checked for consistency rather than a specific threshold. As a general rule, the rate will range from 40% to 75%, but higher or lower rates are not a bad thing. There is a lower limit: any result below 22% will result in a velocity error, as it is considered insufficient to determine a velocity.

In short, this indicator provides information on the amount of information remaining once the non-speed-related components have been eliminated from the return signal. For example, a value of 54% means that 46% of the return signal was considered to be unrelated to velocity.

Homogeneity of flow direction

This quality indicator gives the signal strength in the indicated direction of flow. The value should be equal to or close to 100% most of the time. It is possible to have a value of 100% indicating forward speed, or 100% indicating reverse speed. In all events, the desired result is 100%, or a constant HIGH number.

Bidirectional components are always present in the return signal. Even flow hitting the front end of the sensor creates a vortex, resulting in negative velocity components due to the fact that the flow has to move over or around the sensor. Other flow characteristics may also indicate the opposite direction. A highly turbulent application will have many bidirectional components

- 100% means that, whatever the direction of the reported flow, the information received in that direction is 100 times greater than in the opposite direction.
- 50% means 50 times more.
- 0% means it has received a signal indicating both forward and reverse in roughly equal proportions. 0% always means that the velocity measurement has failed and is erroneous.

Flow rate

- To calculate the flow rate, please refer to the excel form available via the link on Avelour.
- Fill in the height/surface table by clicking on .



Change measure period on threshold



Define a level



Direction: Defines whether the measured level threshold passes **go above a level** or **on rise of at least**.

Value : Sets the height threshold.

Hysteresis : Value to be subtracted from or added to the threshold.

Delay to validate activation : Time at which threshold is reached.

Delay to validate deactivation : Time after which the threshold is no longer reached.

Anticipate data sending : Data transmission can be forced to activation, deactivation or both.

Repeat sending : If data transmission on activation is selected, enables you to modify the data transmission period.

If anticipate data sending is activated, when the threshold is reached, an alert SMS is sent to an operator if this option is configured (see *Sending an alert SMS*).



Set a second threshold



Direction: Defines whether the measured level passes **above a high level** or **below a low level**.

Value : Height threshold.

Hysteresis : Value to be subtracted from/added to threshold.

Delay to validate activation : Time at which threshold is reached.

Delay to validate deactivation : Time after which the threshold is no longer reached.

Anticipate data sending : Data transmission can be forced to activation, deactivation or both.

Repeat sending : If a data send on activation is selected, the data can be returned after a defined period.

If anticipate data sending is activated, when the threshold is reached, an alert SMS is sent to an operator if this option is configured (see *Sending an alert SMS*).

Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.



Mapping table between DataID, channel & data

DataId	Channel	Data displayed	Units	Data Description	Data files
3	7	Debug (Entier signé)	mAh	Internal battery current consumption	*_diag.bin
6	0	Voltage	V	Instantaneous internal battery voltage (Res. 0.05 V)	*_diag.bin
6	1	Voltage	V	Minimum internal battery voltage reached (Res. 0.05 V)	*_diag.bin
6	2	Voltage	V	Instantaneous external battery voltage (Res. 0.05 V)	*_extbat.bin, *_extvolt.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
12	0	Measure temperature	°C	Sensor temperature measurement (Res. 0.1°C)	*_iavl.bin
15	0	Material height	mm	Piezoresistive water height	*_iavl.bin
17	0	GSM signal Power	dBm	GSM signal power	*_diag.bin
19	0	Date	-	POSIX time	Asynchronous data
20/0	0-7	Overflow/State	-	First threshold event	*_iavlt1.bin
20/0	0-7	Overflow/State	-	Second threshold event	*_iavlt2.bin
24	0	Velocity	mm/s	Doppler velocity	*_iavl.bin
25	0	Doppler signal quality	%	Useful signal quantity	*_iavl.bin
25	1	Doppler signal quality	%	Particle density	*_iavl.bin
25	2	Doppler signal quality	%	Homogeneity of flow direction	*_iavl.bin
34	0	Flow rate	m³/s	Water flow rate	*_iavl.bin
39	0-15	Volume	m³	Infinite volume accumulation	*_iavl.bin
39	0-15	Volume	m³	Periodic volume accumulation	*_voliavl.bin

9.6.5. Doppler velocity measurement (Nivus sensor)

Principle

The Nivus wedge and cylindrical sensors measure velocity by the Doppler effect. Placed opposite to the direction of flow, the principle is to measure the speeds of bubbles and/or particles present in water. The hypothesis being that they move at the same speed as water.

Configuration

Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger*.

- Click ⊕ to add a measurement configuration and select “Nivus sensor: Doppler speed measurement".



Doppler settings

Transmit frequency : Select the sensor type *Wedge 1000 kHz* or *cylindrical 750 kHz*.

Damping period (s): Sliding average over time (minimum and by default 5 seconds).

- Activate recording of the following data as necessary:
  - temperature
  - Doppler measurement quality
  - piezoresistive height (1000 kHz wedge sensor)

Verify that the Doppler sensor is properly equipped with a pressure sensor.

Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.



9.6.6. Doppler velocity and overflow measurement (Nivus sensor)

Principle

The Nivus wedge and cylindrical sensors measure velocity by the Doppler effect. Placed in the opposite direction to the flow, its principle is to measure the velocities of bubbles and/or particles present in the water, assuming that they are moving at the same speed as the water.

The NIVUS sensor makes it possible to measure the water level using a built-in piezoresistive sensor.

Configuration

Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger*.

- Click ⊕ to add a measurement configuration and select “Nivus sensor: Doppler velocity measure and overflow (optional flow)".



Doppler parameters

Transmit frequency : Select sensor type *`Wedge 1000 kHz`* or *`cylindrical 750 kHz`*.

Damping period(s): Sliding average over time (minimum 5 seconds)

Temperature record : The sensor is fitted with a temperature probe.

Doppler measure quality record

Height / Flow options for Doppler sensor with integrated piezoresistive height measure



- Activate **Piezoresistive height record** if necessary.
- Enter an offset on the measured height if the sensor is not placed at the bottom of the structure where we wish to measure the height.



- Click Calibrate if necessary to adjust the value measured by the IAVL sensor to the actual height value.
- Fill in the height/surface table by clicking on .

Overflow configuration

Overflow sensor peripheral device: see *M12 8-pin connector*

- Activate a **Velocity measurement period excluding overflow** to change the measure period.
- Activate**overflow recording** to record overflow states (0 or 1).
- Activate the **Periodic overflow data transmission** and in this case enter the minimum time between two data transmissions (see *Configure an alarm*).

Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.



9.6.7. Flow measurement: Doppler speed + built-in piezoresistive height (Nivus sensor)

Principle

The NIVUS sensor makes it possible to measure the water level using a built-in piezoresistive sensor.

Configuration

Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger*.

- Click ⊕ to add a measurement configuration and select “Nivus sensor: Doppler speed + integrated piezoresistive height -> Flow".

Combined Doppler speed/piezoresistive height sensor



- Enter an **offset** on the measured height if the sensor is not placed at the bottom of the structure where we wish to measure the height **H**.



- Click ⚡ Calibrate if necessary to adjust the measured value with the actual height value.

Modifying the frequency of measurements on a measurement threshold

- Activate ⬤ as needed **change measure period on height threshold** to view configuration settings.

Modification of measures to: New measurement frequency.

Direction: Defines whether the measured level exceeds **a high threshold** or **a low threshold**.

Height : Threshold to be reached to activate modification.

Hysteresis : Value to be subtracted (high threshold) or added (low threshold) to the level at which the measurement frequency returns to its initial value.

Minimum time before deceleration : Hold time for the new measurement frequency before returning to its initial value.

Example below: The measurement frequency increases from 15 minutes to 2 minutes if the water level exceeds 500 mm. When the water level falls below the threshold of 400 mm, it returns to 15 minutes.



Doppler settings

Transmit frequency : Choice of the type of sensor, wedge 1000 kHz or cylindrical 750 kHz.

Damping period (s): Sliding average over time (minimum 5 seconds).



Debit

- To calculate the flow rate, refer to the excel form available via the link on Avelour.
- Fill in the height/surface table by clicking on .



Fifo Memory (Advanced Setting)

By default, when the logger memory is full, data are deleted in chronological order of recording, from oldest to newest.

- Click to display advanced settings.
- If Fifo memory is disabled, change the maximum number of timestamps for the main memory (used for sending data via Internet) and the auxiliary memory (used for sending data via SMS) if necessary.



Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.



9.6.8. Physical-chemical measurement

Principle

C4E physical-chemical sensor:

The electrode uses 4-electrode technology: an alternating current of constant voltage is established between a pair of primary graphite electrodes. Secondary platinum electrodes make it possible to regulate the voltage imposed on the primary electrodes, to take account of fouling. The voltage measured between the primary electrodes depends on the resistance of the medium and therefore of its conductivity.

CTZN physical-chemical sensor

A toroidal coil is excited at a fixed frequency and the response is retrieved on a second coil aligned on the first. The coupling depends on conductivity and occurs through the intermediary of the conductive solution.

NTU physical-chemical sensor

The measurement principle is based on nephelometry: a diode emits an Infra-Red light (880nm) and a receiving diode placed at 90° measures the scattered radiation (normalized measurement). The sensor can be calibrated using a Formazine standard.

OPTOD physical-chemical sensor

The OPTOD® dissolved oxygen sensor uses optical luminescence measurement technology approved by ASTM International Method D888-05. This innovative method ensures reliable, accurate measurements without calibration. The OPTOD sensor enables an immediate return on investment as it requires no consumables or maintenance. Only the DoDisk needs to be changed every two years. As it does not consume oxygen, the OPTOD sensor is suitable for all environments, including those with very low water circulation.

PHEHT physical-chemical sensor

The sensor integrates an Ag/AgCl type refernce electrode, used for pH and Redox measurements, with a plasticized electrolyte saturated with KCl “PLASTOGEL”®.

The “PLASTOGEL"® electrolyte communicates directly with the external environment without the interposition of capillaries or pores. There is therefore no risk of blocking or de-priming the reference. The measurement electrodes take the form of a special glass bulb sensitive to pH and soldered to the end of a crystal tube for pH and in the form of a platinum tip for redox.

Configuration

Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger*.

The sensor is connected to the logger.

- Click ⊕ to add a measurement configuration and select “Physicochemical measurement (conductivity, turbidity, pH, dissolved oxygen)".
- Select a period between each measurement from the list. In the example above, a measurement will be taken every 15 minutes.



Power supply

It is possible to power an external sensor directly from the internal battery of the logger. In this case, no specific settings are required.

It is also possible to use an external battery or AC power supply (7-30 V).

- If an external power supply (battery or mains) is connected to the logger, refer to paragraph *Using a power pack*

By default, the power supply delay is set to 800 ms.

C4E conductivity sensor

Data to record : Conductivity or salinity or Conductivity + salinity.

Measurement range : Corresponds to the measurement range of the sensor according to the expected levels.

- Click the button to start a test measurement and display the result.

Define a threshold

- See *the section called "Define a threshold"*.

Change the measurement period (advanced setting)

- Click to display the measurement period parameter (4000 ms by default).

Change Modbus ID

- Click to view and edit the **Modbus ID.**

CTZ induction conductivity sensor

Data to record : Salinity (g/kg), Conductivity (µS/cm), Conductivity + Salinity (µS/cm)

Measurement range : Corresponds to the measurement range of the sensor according to the expected levels.

- Click the button to start a test measurement and display the result.

Define a threshold

- See *the section called "Define a threshold"*.

Change the measurement period (advanced setting)

- Click to show the setting for **measurement period** (4000 ms by default).

Change Modbus ID

- Click to view and edit the **Modbus ID.**

NTU turbidity sensor

Data to record : FNU Turbidity (FNU), Turbidity (FNU + TU), or Turbidity (TU) (mg/L)

Measurement range : Corresponds to the measurement range of the sensor according to the expected levels.

- Click the button to start a test measurement and display the result.

Define a threshold

- See *the section called "Define a threshold"*.

Change the measurement period (advanced setting)

- Click to display the measurement period parameter (4000 ms by default).

Change Modbus ID

- Click to view and edit the **Modbus ID.**

PHEHT Ph and Redox sensor

Data to record : pH, Redoc (mV) or pH + Redox

Measurement range : Corresponds to the measurement range of the sensor according to the expected levels.

- Click the button to start a test measurement and display the result.

Define a threshold

- See *the section called "Define a threshold"*.

Change Modbus ID

- Click to view and edit the **Modbus ID.**

OPTOD optical dissolved oxygen sensor

Data to record : `Oxygen saturation` (%Sat), `Dissolved oxygen` (mg/L) or `Dissolved oxygen + saturation`.

Measurement range : Corresponds to the measurement range of the sensor according to the expected levels.

- Click the button to start a test measurement and display the result.

Define a threshold

- See *the section called "Define a threshold"*.

Check correct sensor operation

- Click to view the measured values.

  -> The connection to the device is activated and a new window displays the measured values.

Change Modbus ID

- Click to view and edit the **Modbus ID.**

Define a threshold



Threshold parameter : Measurement parameter to select according to the type of sensor.

Threshold criterion : Criterion defining the type of crossing:

- Go below a level: measured level passes below the configured threshold.
- Go above a high level: the measured level exceeds the configured threshold.
- On rise of at least: the value between 2 measurements exceeds the configured threshold.
- On high and low threshold: measured level exceeds the high threshold or drops below the low threshold.

Hysteresis : Value to be subtracted/added to the threshold for which its state is deactivated.

Record events : Threshold crossing state = 0 or 1.

Anticipate data sending : Data transmission may be forced upon activation, deactivation or both.

Repeat sending : If data transmission on activation is selected, enables you to modify the data transmission period.

If anticipate data sending is activated, an alert SMS is sent to an operator when the threshold is reached, if this option is configured (see *Sending an alert SMS*).


Level
Criterion = On high and low threshold
Maximum value
Hysteresis
Minimum value
T
State = 0
State = 0
Data sending
+ State =1
Data sending
+ State =1
Text is not SVG - cannot display


Level
Criterion = Exceeds a high threshold
Criterion = Drops below a low threshold
Hysteresis
Threshold
Hysteresis
T
Data transmission + State = 1
Data transmission + State = 1
State = 0
State = 0



Fifo Memory (Advanced Setting)

By default, when the logger memory is full, data are deleted in chronological order of recording, from oldest to newest.

- Click to display advanced settings.
- If Fifo memory is disabled, change the maximum number of timestamps for the main memory (used for sending data via Internet) and the auxiliary memory (used for sending data via SMS) if necessary.



Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.



Mapping table between DataID, channel & data

DataId	Channel	Data displayed	Units	Data Description	Data files
0	0	State	-	Threshold event for conductivity C4E sensor	*_eventC4E.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
0	1	State	-	Threshold event for conductivity CTZ sensor	*_eventCTZ.bin
0	2	State	-	Threshold event for turbidity NTU sensor	*_eventNTU.bin
0	3	State	-	Threshold event for pH and Redox PHEHT sensor	*_eventPHEHT.bin
0	4	State	-	Threshold event for oxygen OPTOD sensor	*_eventOPTOD.bin
3	7	Debug (signed integer value)	mAh	Internal battery current consumption	*_diag.bin
6	0	Voltage	V	Instantaneous internal battery voltage (Res. 0.05 V)	*_diag.bin
6	1	Voltage	V	Minimum internal battery voltage reached (Res. 0.05 V)	*_diag.bin
6	2	Voltage	V	Instantaneous external battery voltage (Res. 0.05 V)	*_extvolt.bin, *_extbat.bin
12	0	Measure temperature	°C	C4E conductivity sensor temperature measurement (Res. 0.1°C)	*_ponsel.bin
12	1	Measure temperature	°C	CTZ conductivity sensor temperature measurement (Res. 0.1°C)	*_ponsel.bin
12	2	Measure temperature	°C	NTU turbidity sensor FNU temperature measurement (Res. 0.1 °C)	*_ponsel.bin
12	3	Measure temperature	°C	PHEHT pH and Redox sensor temperature measurement (Res. 0.1 °C)	*_ponsel.bin
12	4	Measure temperature	°C	OPTOD oxygen sensor temperature measurement (Res. 0.1 °C)	*_ponsel.bin
17	0	GSM signal Power	dBm	GSM signal power	*_diag.bin
19	0	Date	-	POSIX time	Asynchronous data
26	0	Conductivity	µS/cm	C4E conductivity sensor conductivity measurement	*_ponsel.bin
26	1	Conductivity	µS/cm	CTZ conductivity sensor conductivity measurement	*_ponsel.bin
27	0	Salinity	g/kg	C4E conductivity sensor salinity measurement	*_ponsel.bin
27	1	Salinity	g/kg	CTZ conductivity sensor salinity measurement	*_ponsel.bin
28	4	Oxygen saturation	%	OPTOD oxygen sensor oxygen saturation measurement	*_ponsel.bin
29	4	Dissolved oxygen	mg/l	OPTOD oxygen sensor dissolved oxygen measurement	*_ponsel.bin
30	3	pH	-	PHEHT pH and Redox sensor pH measurement	*_ponsel.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
31	3	Redox	mV	PHEHT pH and Redox sensor Redox measurement	*_ponsel.bin
32	2	FNU turbidity	FNU	NTU turbidity sensor FNU turbidity measurement	*_ponsel.bin
33	2	TU turbidity	mg/l	NTU turbidity sensor TU turbidity measurement	*_ponsel.bin

9.6.9. Conductivity measurement (B&C sensor)

Principle

The B&C sensor is used to measure conductivity by induction. An electric current passes through an emission coil to induce a magnetic field in the liquid. A current is then applied to the ions present in the liquid. This current is measured by a receiving coil and makes it possible to define the conductivity of the liquid.

Configuration

Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger*.

- Click ⊕ to add a measurement configuration and select “B&C sensor”.



Measurement parameters with a B&C sensor

Measure period

- From the list, select a length of time between each measurement. In the example above, a measurement will be taken every 15 minutes.

Power supply

It is possible to power an external sensor directly from the internal battery of the logger. In this case, no specific settings are required.

It is also possible to use an external battery or AC power supply (7-30 V).

- If an external power supply (battery or mains) is connected to the logger, refer to paragraph *Using a power pack*

For the B&C sensor, the possible voltage ranges from a minimum of 9 V to a maximum of 36 V.

By default, the power supply delay is set at 3000 ms (3 seconds), which corresponds to the time required for the B&C conductivity sensor.

Measuring range

Two different ranges are available: 0 — 4 mS/cm or 0 — 200 mS/cm

- Select the range according to the expected conductivity values.

Temperature

- Activate recording of the temperature measured by the sensor if necessary.

View measured values

- Click the button on the left to display the measured conductivity and temperature values.
- Click the button on the right to show the sensor configuration.

Fifo Memory (Advanced Setting)

By default, when the logger memory is full, data are deleted in chronological order of recording, from oldest to newest.

- Click to display advanced settings.
- If Fifo memory is disabled, change the maximum number of timestamps for the main memory (used for sending data via Internet) and the auxiliary memory (used for sending data via SMS) if necessary.



Configuration summary

- Click SEE OVERVIEW to display a summary of the configuration.

Depending on the parameters selected, the recording time remaining before the memory is full is also given, as well as an average of the number of text messages sent per day.



9.6.10. Measurement using an ISCO signature flow meter

Principle

The Signature flow meter is designed for open channel flow monitoring applications, using any combination of sampling and measurement technologies for flow rates and other parameters, and as required by the monitoring site.

Configuration

Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger*.

- Click to add a measurement configuration and select “ISCO Signature flow meter".



Datalogging period

- From the list, select a length of time between each measurement. In the example above, a measurement will be taken every 15 minutes.

Information: For each data element, the recording channels respect the order assigned during configuration of the Signature flow meter

Data to record

It is possible to view a document by clicking on the link " More information here ". For each data element measured by an Ijinus logger, this document named “Modbus Tables” describes the address, the offset, the size and the encoding (integer, inverted integer, etc.).

Depending on the type of application chosen in the drop-down menu shown below, the table applied (and therefore the data encoding) will not be the same. You must therefore use the correct register table to be able to send the desired measurements to the PLC.

- Activate the data to be recorded as needed.
- Select the recording **Number** of the parameter activated based on the Signature flowmeter configuration.

Fifo Memory (Advanced Setting)

By default, when the logger memory is full, data are deleted in chronological order of recording, from oldest to newest.

- Click to display advanced settings.
- If Fifo memory is disabled, change the maximum number of timestamps for the main memory (used for sending data via Internet) and the auxiliary memory (used for sending data via SMS) if necessary.



Modbus configuration

These parameters must coincide exactly with the parameters expected by the controller connected to the Ijinus logger.

Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.



Mapping table between DataID, channel & data

DataId	Channel	Data displayed	Units	Data Description	Data files
3	7	Debug (signed integer value)	mAh	Internal battery current consumption	*_diag.bin
6	0	Voltage	V	Instantaneous internal battery voltage (Res. 0.05 V)	*_diag.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
6	1	Voltage	V	Minimum internal battery voltage reached (Res. 0.05 V)	*_diag.bin
6	2	Voltage	V	Instantaneous external battery voltage (Res. 0.05 V)	*_extbat.bin, *_extvolt.bin
12	0	Measure temperature	°C	Sensor 1 temperature measurement (Res. 0.1°C)	*_signISCO_0.bin
12	1	Measure temperature	°C	Sensor 2 temperature measurement (Res. 0.1°C)	*_signISCO_0.bin
12	2	Measure temperature	°C	Sensor 3 temperature measurement (Res. 0.1°C)	*_signISCO_0.bin
12	3	Measure temperature	°C	Sensor 4 temperature measurement (Res. 0.1°C)	*_signISCO_0.bin
15	0	Material height	mm	Sensor 1 water height	*_signISCO_0.bin
15	1	Material height	mm	Sensor 2 water height	*_signISCO_0.bin
15	2	Material height	mm	Sensor 3 water height	*_signISCO_0.bin
15	3	Material height	mm	Sensor 4 water height	*_signISCO_0.bin
17	0	GSM signal Power	dBm	GSM signal power	*_diag.bin
19	0	Date	-	POSIX time	Asynchronous data
24	0	Velocity	mm/s	Sensor 1 water velocity	*_signISCO_1.bin
24	1	Velocity	mm/s	Sensor 2 water velocity	*_signISCO_1.bin
24	2	Velocity	mm/s	Sensor 3 water velocity	*_signISCO_1.bin
24	3	Velocity	mm/s	Sensor 4 water velocity	*_signISCO_1.bin
26	0	Conductivity	µS/cm	Sensor 1 water conductivity	*_signISCO_2.bin
26	1	Conductivity	µS/cm	Sensor 2 water conductivity	*_signISCO_2.bin
26	2	Conductivity	µS/cm	Sensor 3 water conductivity	*_signISCO_2.bin
26	3	Conductivity	µS/cm	Sensor 4 water conductivity	*_signISCO_2.bin
30	0	pH	-	Sensor 1 water pH	*_signISCO_2.bin
30	1	pH	-	Sensor 2 water pH	*_signISCO_2.bin
30	2	pH	-	Sensor 3 water pH	*_signISCO_2.bin
30	3	pH	-	Sensor 4 water pH	*_signISCO_2.bin
34	0	Flow rate	m3/s	Sensor 1 water flow rate	*_signISCO_0.bin
34	1	Flow rate	m3/s	Sensor 2 water flow rate	*_signISCO_0.bin
34	2	Flow rate	m3/s	Sensor 3 water flow rate	*_signISCO_0.bin
34	3	Flow rate	m3/s	Sensor 4 water flow rate	*_signISCO_0.bin
39	0	Volume	m3	Sensor 1 water volume	*_signISCO_0.bin
39	1	Volume	m3	Sensor 2 water volume	*_signISCO_0.bin
39	2	Volume	m3	Sensor 3 water volume	*_signISCO_0.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
39	3	Volume	m3	Sensor 4 water volume	*_signISCO_0.bin

9.6.11. Configure a wired modbus display on push-button

Operation

Data from the wired sensor is displayed by pressing the push button below the display.

The modem and the display cannot work simultaneously. Priority is given to the one that is currently in operation.

If the display is active, activation of the modem (data transmission) is postponed for 60 seconds.

Display configuration

Prerequisite: In Avelour, the Wiji connection to the logger must be established, see. *Connecting to a logger*

- Click on to add a measurement configuration and select " Modbus wired display with switch".



By default, when the display button is pressed, a measurement is taken. It is then possible to activate logging of this measurement.

Configuration summary

To view the configuration summary:

- Click on SEE OVERVIEW to display a summary of the configuration.



9.6.12. Wired overflow detector

Principle

An OVERFLOW overflow detector can record the number and duration of overflows and communicate them if physically connected to the logger.

An OVERFLOW overflow detector operates using an air-reference capacitive measurement that consumes very little energy.

The OVERFLOW detector takes into account elements in physical contact with the housing and up to a few centimeters away from it. The detector is highly insensitive to fouling. It is possible to adjust the overflow recording threshold to take account of restrictive external conditions in particularly congested networks.

Configuration

Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger-* parameters.

- Click to add a measurement configuration and select “Wired overflow".



Configuration

Activation / deactivation processing time : A time delay can be set for activation and deactivation of the overflow state.

Anticipate data transmission : Data transmission can be forced to activation, deactivation or both overflow states.

Repeat transmission : Activates modification of the data transmission cycle.

Cumulate the time spent in overflow all the: Define a recording frequency for cumulative time spent in overflow.

Modbus functionalities (CSC-810-MOD)

Read the configured detection threshold : Click to display the threshold set on the detector.

CSC slave address select the expected channel as configured in Modbus master.

Modify the detection threshold

Desired detection threshold: define the percentage of the capacitive saturation detection threshold.

A 5% hysteresis is set on the capacitive saturation value threshold before state change. This means that for a value set at 80%, the overflow state will no longer be active as soon as the value falls below 75%.

- Click **Run** so that the updated detection threshold is taken into account on the detector.

Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.



Table of correspondences (Data ID / Channel / files)

DataId	Channel	Data displayed	Units	Data Description	Data files
6	0	Voltage	V	Instantaneous internal battery voltage (Res. 0.05 V)	*_diag.bin
6	1	Voltage	V	Minimum internal battery voltage reached (Res. 0.05 V)	*_diag.bin
7	0	Voltage	V	Instantaneous internal overflow battery voltage (Res. 0.01 V) - Channel 1	*_diagOv.bin
7	1	Voltage	V	Instantaneous internal overflow battery voltage (Res. 0.01 V) - Channel 2	*_diagOv.bin
11	0	System temperature	°C	System temperature of the overflow device - Channel 1	*_mbCap.bin
11	1	System temperature	°C	System temperature of the overflow device - Channel 2	*_mbCap2.bin
17	0	GSM signal Power	dBm	GSM signal power	*_diag.bin
19	0	Date	-	POSIX time	Asynchronous data
20	0	Overflow	-	Overflow status - Channel 1	*_ovhard.bin
20	1	Overflow	-	Overflow status - Channel 2	*_ovhard2.bin
23	0	Capacitive saturation	%	Capacitive saturation of the overflow device - Channel 1	*_mbCap.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
23	1	Capacitive saturation	%	Capacitive saturation of the overflow device - Channel 2	*_mbCap2.bin
40	0	Duration	s	Cumulated time spent in overflow on defined period - Channel 1	*_ovhReport.bin
40	1	Duration	s	Infinite cumulated time spent in overflow - Channel 1	*_ovhard.bin
40	2	Duration	s	Cumulated time spent in overflow on defined period - Channel 2	*_ovhReport2.bin
40	3	Duration	s	Infinite cumulated time spent in overflow - Channel 2	*_ovhard2.bin

9.6.13. Modbus master

Principle

The modbus master configuration is a tool for performing read, write and delay operations directly in modbus 485 communication.

Configuration

The configuration of the recorder in modbus master mode is intended for expert users to configure products directly in modbus 485 communication. It therefore represents an alternative to the products/tools directly integrated by Ijinus. However, it is important to know the prerequisites for using this tool.

Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger*.

- Click ⊕ to add a measurement configuration and select “Modbus master".



Modbus configuration

It is essential that these parameters match exactly with the product connected in modbus slave.



Default master modbus configuration

Sequence of commands

Read register

Read register commands are limited to 8 maximum.

To add a register reading, click .



- Modbus function 0x03 or 0x04
- Format of the data read: Unsigned16, Signed16, Unsigned32, Signed32, Float
- **Byte order** possible depending on the format: AB, BA, ABCD (W1W2), DCBA, CDAB (W2W1), BADC
- **Function** modbus 0x03 or 0x04
- Read value converted to the chosen Ijinus datatype.
- Possible linear conversion of the value: Value = A * (X + B) + C
- Button to test the command in expert mode.

Write to register

Read register commands are limited to 8 maximum.

To add a register entry, click .



- **Format** of written data: Unsigned16, Signed16, Unsigned32, Signed32, Float
- **Byte order** possible depending on the format: AB, BA, ABCD (W1W2), DCBA, CDAB (W2W1), BADC
- **Function** modbus 0x06 or 0x10
- **Value to write** : Write a constant to the target register

Add a delay

Delay commands are limited to 8 maximum.

- To add a delay between two commands, click and enter a delay in ms.

Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.

Depending on the selected settings, the remaining recording time before the memory is full is given as well as an average of the number of SMS sent per day.



9.6.14. Measurement via DI/CO input

Principle

The Contact/Counter input 1-100 is used to detect the closure of a contact on one of the logger's digital inputs, and to record it with the timestamp of the change of state.

Configuration

Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger*.

- Click ⊕ to add a measurement configuration and select “DI/CO input”.



Each change of state is time-stamped. Furthermore, the state of the input will be measured every hour by default.

- Click 🔧 to disable hourly state recording.

A change of state can also be detected and recorded on a second channel.

Fifo memory 🔧

By default, when the logger's memory is full, data is deleted in chronological order of recording, from oldest to most recent.

- If Fifo memory is disabled, define a maximum number of timestamps.



Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.



Mapping table between DataID, channel & data

DataId	Channel	Data displayed	Units	Data Description	Data files
0	0	State	-	DI 1 status	*_di1.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
0	1	State	-	DI 2 status	*_di2.bin
3	7	Debug (signed integer value)	mAh	Internal battery current consumption	*_diag.bin
6	0	Voltage	V	Instantaneous internal battery voltage (Res. 0.05 V)	*_diag.bin
6	1	Voltage	V	Minimum internal battery voltage reached (Res. 0.05 V)	*_diag.bin
17	0	GSM signal Power	dBm	GSM signal power	*_diag.bin
19	0	Date	-	POSIX time	Asynchronous data

9.6.15. Modbus flow meter

Principle

The "Modbus flowmeter" measurement configuration enables data to be recorded using a flowmeter via Modbus communication, slave mode.

Flowmeter wiring



For correct operation of the flowmeter in MODBUS mode, you need to connect the ground wire. (See paragraph *???*)

Configuration



Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger*.

- Click  to add a measurement configuration and select “Modbus Flowmeter”.



- Select the **Recording period** corresponding to the time between each recording (every 15 minutes for example).
- Select the type of **flow meter** connected to the logger.



List of selectable flowmeters

- Activate if necessary recording of **volume**, **flow**, **pressure**, **temperature**, **battery capacity** And **direction** parameters.

MODBUS parameter

ABB - AQUAMASTER4

Baudrate : 19200, Bit number : 8, Parity : Even, Stop bit : 1

For wiring, refer to the paragraph *la section intitulée « ABB Aqua master 4 »*

ARAD - OCTAVE

Baudrate : 9600, Bit number : 8, Parity : Even, Stop bit : 1

For wiring, refer to the paragraph *la section intitulée « ARAD - Octave »*

ENLESS+HAUSER - PROMAG W800

Baudrate : 9600, Bit number : 8, Parity : Even, Stop bit : 1

For wiring, refer to the paragraph *la section intitulée « HENDLESS+HAUSER - Promag W 800 »*

FUJI ELECTRIC - M5000

Baudrate : 9600, Bit number : 8, Parity : Even, Stop bit : 1

For wiring, refer to the paragraph *_M5000*

KROHNE - WATERFLUX 3070

Baudrate : 9600, Bit number : 8, Parity : Even, Stop bit : 1

For wiring, refer to the paragraph *_3070*

SIEMENS - MAG 8000

Baudrate : 19200, Bit number : 8, Parity : Even, Stop bit : 1

For wiring, refer to the paragraph *_MAG8000*

Modbus slave ID (Advanced parameter)

To enter the Modbus slave ID:

- Click to display advanced settings.



Flow calculation

If an hourly flow is activated then it is possible to calculate this hourly volume.

- Enter start and end times.
- Activate if necessary the type of calculation recorded: an **average**, a **minimum** flow rate and/or a **maximum** flow rate.



Check sensor operation

- Click to view measured values.

  -> Connection to the device is initiated and a new window displays the measured values.

Fifo memory

By default, when the logger's memory is full, data is deleted in chronological order of recording, from oldest to most recent.

- If Fifo memory is disabled, define a maximum number of timestamps.



Configuration summary

To view the configuration summary:

- Click on SEE OVERVIEW to display a summary of the configuration.



Table of datatype correspondences

This file contains, for each brand of flow meter, the correspondence between the type of data recorded (volume, flow rate, pressure, etc.) and the number encoded by the Ijinus logger (datatype). As several identical types of data can be recorded, a channel number is also added to the datatype.

MAG 8000

Displayed Data	DataID	Channel	Unités	Description	Data Files
Modbus register	21	20	-	Fault status	*_mag8000.bin
Modbus register	21	21	-	Configuration	*_mag8000.bin
Velocity	24	20	mm/s	Velocity	*_mag8000.bin
Flow rate	34	20	m³/s	Flow rate	*_mag8000.bin
Volume	39	20	m³	Forward volume 1	*_mag8000.bin
Volume	39	21	m³	Reverse volume 2	*_mag8000.bin
Volume	39	22	m³	Forward volume 2	*_mag8000.bin
Volume	39	24	m³	Total volume 1	*_mag8000.bin

Debug (signed integer value)	3	20	m³	Forward volume 1 (integer m³)	*_mag8000.bin
Debug (signed integer value)	3	21	m³	Reverse volume 1 (integer m³)	*_mag8000.bin
Debug (signed integer value)	3	22	m³	Forward volume 2 (integer m³)	*_mag8000.bin
Debug (signed integer value)	3	24	m³	Total volume 1 (integer m³)	*_mag8000.bin
Debug (positive integer value)	2	22	%	Flowmeter battery charge state	*_mag8000.bin
Counter	22	26	-	Hour of minimum night flow rate	*_min-fm.bin
Counter	22	27	-	Hour of maximal night flow rate	*_max-fm.bin
Volume	39	25	m³	Hourly volume	*_hourlyflow-fm.bin
Volume	39	26	m³	Minimum night flow rate	*_min-fm.bin
Volume	39	27	m³	Maximum night flow rate	*_max-fm.bin
Volume	39	28	m³	Average flow rate	*_moy-fm.bin
Volume	39	30	m³	24-hour volume	*_dai-lyflow-fm.bin
Volume	39	31	m³	Weekly volume	*_week-lyflow-fm.bin
Volume	39	32	m³	Monthly volume	*_month-lyflow-fm.bin
State	0	20	-	Threshold state change	*_thres-event-fm.bin
Debug (signed integer value)	3	7	mAh	Internal battery current capacity consumption	*_diag.bin
GSM signal Power	17	0	dBm	GSM signal power	*_diag.bin
Voltage	6	0	V	Instantaneous battery voltage (Res. 0.05 V)	*_diag.bin
Voltage	6	1	V	Minimum battery voltage reached (Res. 0.05 V)	*_diag.bin

Waterflux 3070

Displayed Data	DataID	Channel	Unités	Description	Data Files
Debug (positive integer value)	2	20	-	Flow direction	*_waterflux.bin

Debug (positive integer value)	2	21	-	Alarms	*_waterflux.bin
Debug (Real value)	4	20	Ah	Remaining flowmeter battery capacity	*_waterflux.bin
Temperature	12	20	°C	Liquide temperature (Res. 0.1 °C)	*_waterflux.bin
Velocity	24	20	mm/s	Velocity	*_waterflux.bin
Flow rate	34	20	m³/s	Flow rate	*_waterflux.bin
Pressure	37	20	bar	Liquid pressure	*_waterflux.bin
Volume	39	20	m³	Forward volume	*_waterflux.bin
Volume	39	21	m³	Reverse volume	*_waterflux.bin
Volume	39	24	m³	Total volume	*_waterflux.bin
Counter	22	26	-	Hour of minimum night flow rate	*_min-fm.bin
Counter	22	27	-	Hour of maximal night flow rate	*_max-fm.bin
Volume	39	25	m³	Hourly volume	*_hourlyflow-fm.bin
Volume	39	26	m³	Minimum night flow rate	*_min-fm.bin
Volume	39	27	m³	Maximum night flow rate	*_max-fm.bin
Volume	39	28	m³	Average flow rate	*_moy-fm.bin
Volume	39	30	m³	24-hour volume	*_dailyflow-fm.bin
Volume	39	31	m³	Weekly volume	*_weeklyflow-fm.bin
Volume	39	32	m³	Monthly volume	*_monthlyflow-fm.bin
State	0	20	-	Threshold state change	*_thres-event-fm.bin
Debug (signed integer value)	3	7	mAh	Internal battery current capacity consumption	*_diag.bin
GSM signal Power	17	0	dBm	GSM signal power	*_diag.bin
Voltage	6	0	V	Instantaneous battery voltage (Res. 0.05 V)	*_diag.bin
Voltage	6	1	V	Minimum battery voltage reached (Res. 0.05 V)	*_diag.bin

M5000

Displayed Data	DataID	Channel	Unités	Description	Data Files
Modbus register	21	20	-	Fault	*_m5000.bin
Modbus register	21	21	-	Flow direction	*_m5000.bin
Velocity	24	20	mm/s	Velocity	*_m5000.bin
Flow rate	34	20	m³/s	Flow rate	*_m5000.bin
Volume	39	20	m³	Forward volume 1	*_m5000.bin
Volume	39	21	m³	Reverse volume 1	*_m5000.bin
Volume	39	22	m³	Forward volume 2	*_m5000.bin
Volume	39	23	m³	Reverse volume 2	*_m5000.bin
Volume	39	24	m³	Total volume	*_m5000.bin
Counter	22	26	-	Hour of minimum night flow rate	*_min-fm.bin
Counter	22	27	-	Hour of maximal night flow rate	*_max-fm.bin
Volume	39	25	m³	Hourly volume	*_hourlyflow-fm.bin
Volume	39	26	m³	Minimum night flow rate	*_min-fm.bin
Volume	39	27	m³	Maximum night flow rate	*_max-fm.bin
Volume	39	28	m³	Average flow rate	*_moy-fm.bin
Volume	39	30	m³	24-hour volume	*_dai-lyflow-fm.bin
Volume	39	31	m³	Weekly volume	*_week-lyflow-fm.bin
Volume	39	32	m³	Monthly volume	*_month-lyflow-fm.bin
State	0	20	-	Threshold state change	*_thres-event-fm.bin
Debug (signed integer value)	3	7	mAh	Internal battery current capacity consumption	*_diag.bin
GSM signal Power	17	0	dBm	GSM signal power	*_diag.bin
Voltage	6	0	V	Instantaneous battery voltage (Res. 0.05 V)	*_diag.bin
Voltage	6	1	V	Minimum battery voltage reached (Res. 0.05 V)	*_diag.bin

PROMAG w 800

Displayed Data	DataID	Channel	Unités	Description	Data Files

Debug (positive integer value)	2	20	%	Flowmeter battery charge state	*_promag.bin
Debug (positive integer value)	2	21	days	Estimated flowmeter battery lifetime	*_promag.bin
Velocity	24	20	mm/s	Velocity	*_promag.bin
Conductivity	26	20	µS/cm	Conductivity	*_promag.bin
Flow rate	34	20	m³/s	Flow rate	*_promag.bin
Volume	39	20	m³	Forward volume	*_promag.bin
Volume	39	21	m³	Reverse volume	*_promag.bin
Volume	39	24	m³	Total volume	*_promag.bin
Counter	22	26	-	Hour of minimum night flow rate	*_min-fm.bin
Counter	22	27	-	Hour of maximal night flow rate	*_max-fm.bin
Volume	39	25	m³	Hourly volume	*_hourlyflow-fm.bin
Volume	39	26	m³	Minimum night flow rate	*_min-fm.bin
Volume	39	27	m³	Maximum night flow rate	*_max-fm.bin
Volume	39	28	m³	Average flow rate	*_moy-fm.bin
Volume	39	30	m³	24-hour volume	*_dai-lyflow-fm.bin
Volume	39	31	m³	Weekly volume	*_week-lyflow-fm.bin
Volume	39	32	m³	Monthly volume	*_month-lyflow-fm.bin
State	0	20	-	Threshold state change	*_thres-event-fm.bin
Debug (signed in-teger value)	3	7	mAh	Internal battery current capacity consumption	*_diag.bin
GSM signal Power	17	0	dBm	GSM signal power	*_diag.bin
Voltage	6	0	V	Instantaneous battery voltage (Res. 0.05 V)	*_diag.bin
Voltage	6	1	V	Minimum battery voltage reached (Res. 0.05 V)	*_diag.bin

Octave

Displayed Data	DataID	Channel	Unités	Description	Data Files

Debug (positive integer value)	2	20	-	Flow direction	*_.octave.bin
Temperature	12	20	°C	Liquid temperature (Res. 0.1 °C)	*_.octave.bin
Modbus Register	21	20	-	Alarms	*_.octave.bin
Flow rate	34	20	m³/s	Flow rate	*_.octave.bin
Volume	39	20	m³	Reverse volume 1	*_.octave.bin
Volume	39	21	m³	Forward volume 2	*_.octave.bin
Volume	39	24	m³	Total volume	*_.octave.bin
Counter	22	26	-	Hour of minimum night flow rate	*_min-fm.bin
Counter	22	27	-	Hour of maximal night flow rate	*_max-fm.bin
Volume	39	25	m³	Hourly volume	*_hourlyflow-fm.bin
Volume	39	26	m³	Minimum night flow rate	*_min-fm.bin
Volume	39	27	m³	Maximum night flow rate	*_max-fm.bin
Volume	39	28	m³	Average flow rate	*_moy-fm.bin
Volume	39	30	m³	24-hour volume	*_dai-lyflow-fm.bin
Volume	39	31	m³	Weekly volume	*_week-lyflow-fm.bin
Volume	39	32	m³	Monthly volume	*_month-lyflow-fm.bin
State	0	20	-	Threshold state change	*_thres-event-fm.bin
Debug (signed integer value)	3	7	mAh	Internal battery current capacity consumption	*_diag.bin
GSM signal Power	17	0	dBm	GSM signal power	*_diag.bin
Voltage	6	0	V	Instantaneous battery voltage (Res. 0.05 V)	*_diag.bin
Voltage	6	1	V	Minimum battery voltage reached (Res. 0.05 V)	*_diag.bin

Aquamaster

Displayed Data	DataID	Channel	Unités	Description	Data Files
Modbus register	21	20	-	Alarms	*_aqua.bin
Velocity	24	20	mm/s	Velocity	*_aqua.bin
Flow rate	34	20	m³/s	Flow rate	*_aqua.bin

Pressure	37	20	bar	Liquid pressure	*_aqua.bin
Volume	39	20	m³	Forward volume	*_aqua.bin
Volume	39	21	m³	Reverse volume	*_aqua.bin
Volume	39	24	m³	Total volume	*_aqua.bin
Counter	22	26	-	Hour of minimum night flow rate	*_min-fm.bin
Counter	22	27	-	Hour of maximal night flow rate	*_max-fm.bin
Volume	39	25	m³	Hourly volume	*_hourlyflow-fm.bin
Volume	39	26	m³	Minimum night flow rate	*_min-fm.bin
Volume	39	27	m³	Maximum night flow rate	*_max-fm.bin
Volume	39	28	m³	Average flow rate	*_moy-fm.bin
Volume	39	30	m³	24-hour volume	*_dai-lyflow-fm.bin
Volume	39	31	m³	Weekly volume	*_week-lyflow-fm.bin
Volume	39	32	m³	Monthly volume	*_month-lyflow-fm.bin
State	0	20	-	Threshold state change	*_thres-event-fm.bin
Debug (signed integer value)	3	7	mAh	Internal battery current capacity consumption	*_diag.bin
GSM signal Power	17	0	dBm	GSM signal power	*_diag.bin
Voltage	6	0	V	Instantaneous battery voltage (Res. 0.05 V)	*_diag.bin
Voltage	6	1	V	Minimum battery voltage reached (Res. 0.05 V)	*_diag.bin

9.6.16. Measurement using the Modbus protocol : Slave mode

Principle

The Modbus protocol can be used to link the logger to a PLC in order to send measured data. In this case, the logger is in "Modbus slave" mode. This option is not available if the Modbus connection is used in slave mode only ("Modbus flowmeter"). This is because the logger has only one Modbus connection, which can be used either as a Modbus master or as a Modbus slave, but it is not possible to use both connections at the same time.

As Modbus communication is based on a notion of requests and responses, it is essential that the logger remains permanently switched on in Modbus slave mode, and consequently the use of an external power supply is necessary. (See *Using a power pack* or *???*.

Settings

Prerequisite: In Avelour, the Wiji connection with the logger must be established, see *Connecting to a logger*.

- Click on the button to add a configuration measurement and select "Modbus output".

It is essential that these parameters coincide perfectly with the ones expected by the PLC connected to the logger.



Viewing data logs

A document can be displayed by clicking on the "More information here" link. This document, called "Modbus Tables", describes the address, offset, size and encoding (integer, inverted integer, etc.) for each item of data measured by an Ijinus logger.

Depending on the type of application chosen from the drop-down menu shown below, the table applied (and therefore the data encoding) will not be the same. It is therefore essential to use the correct register table to be able to send the desired measurements to the PLC via the Modbus protocol.

Configuration summary

- Click on the "View resume" button to display the summary of the recording configuration.

Depending on the settings selected, the remaining recording time before the memory is full is given as well as an average of the number of sms sent per day.



9.6.17. Recording of bucket toggles

Principle

This configuration allows you to time-stamp each time a bucket tips on a rain gauge connected to the logger.

Numerous tipping bucket rain gauges of different brands can be connected, provided they are equipped with an output signal based on the closure of a "normally open" contact with a minimum duration of 150 ms in the down state each time the buckets are tipped.

Configuration

Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger-parameters.*

- Click to add a measurement configuration and select “Timestamp bucket tips”.



Fifo Memory (Advanced Setting)

By default, when the logger memory is full, data are deleted in chronological order of recording, from oldest to newest.

- Click to display advanced settings.
- If Fifo memory is disabled, change the maximum number of timestamps for the main memory (used for sending data via Internet) and the auxiliary memory (used for sending data via SMS) if necessary.



Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.



Recording of bucket toggles

DataId	Channel	Data displayed	Units	Data Description	Data files
3	7	Debug (signed integer value)	mAh	Internal battery current consumption	*_diag.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
6	0	Voltage	V	Instantaneous internal battery voltage (Res. 0.05 V)	*_diag.bin
6	1	Voltage	V	Minimum internal battery voltage reached (Res. 0.05 V)	*_diag.bin
6	2	Voltage	V	Instantaneous external battery voltage (Res. 0.05 V)	*_extbat.bin
17	0	GSM signal Power	dBm	GSM signal power	*_diag.bin
19	0	Date	-	POSIX time	Asynchronous data
22	0	Counter	-	Recording of bucket toggles	*_toggle.bin

9.6.18. Cumulative Rainfall

Principle

The purpose of this application is to be able to use a rain gauge connected to an Ijinus logger with a digital input. It is possible to connect many different brands of tipping bucket rain gauges provided that it is equipped with an output signal based on the closure of a "normally open" contact for a minimum duration of 150 ms in low state each time the bucket tips.

The logger must be connected to the rain gauge to install using the cable provided. The part fitted with a connector must be inserted into the logger connector.

For rain gauges not supplied by Ijinus, refer to the chapter *M12 8-pin connector*.

Configuration

Prerequisites: In Avelour, the Wiji connection to the logger must be established, see *Connecting to a logger*.

- Click ⊕ to add a measurement configuration and select “Rainfall measurement”.



Peripheral choice

- Define the input path (see *Wiring*).

Rain gauge configuration

Value of the bucket

Depending on the model of rain gauge connected to the logger, the weight of the bucket may be different.

Rain gauge model	Weight of bucket
RG20	0.2 mm
RG25	0.254 mm

Rainfall accumulation on a time basis

- Select the frequency of sliding cumulative rainfall recordings.

Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.

Depending on the selected settings, the remaining recording time before the memory is full is shown, as well as an average of the number of SMS text messages sent per day.



Mapping table between DataID, channel & data

The table below shows the correspondence for the two DI meters between the type of data recorded (volume, flow, pressure, etc.) and the number encoded by the Ijinus logger (datatype). As several identical types of data can be recorded, a channel number is also added to the datatype.

DataId	Channel	Data displayed	Units	Data Description	Data files
0	0	State	-	Threshold event on cumulative precipitation	*_event.bin
3	7	Debug (signed integer value)	mAh	Internal battery current consumption	*_diag.bin
6	0	Voltage	V	Instantaneous internal battery voltage (Res. 0.05 V)	*_diag.bin
6	1	Voltage	V	Minimum internal battery voltage reached (Res. 0.05 V)	*_diag.bin
17	0	GSM signal Power	dBm	GSM signal power	*_diag.bin
19	0	Date	-	POSIX time	Asynchronous data
22	0	Counter	-	Infinite counting of the number of tray flips	*_rain.bin
35	0	Cumul de pluviométrie	mm	Cumulated total precipitation over the cumulation period	*_rain.bin

9.6.19. Measurement for pump station management

Principle



Overview	Number of P1 starts	Number of P2 starts	Number of times P1 and P2 worked together	P1 operating time	P2 operating time	Combined operating time of P1 and P2
Period	'counter[0]'	'counter[1]'	'counter[2]'	'duration[0]' (sec)	'duration[1]' (sec)	'duration[2]' (sec)
T1	2	2	0	$\Delta t_1 + \Delta t_2$	$\Delta t'_1 + \Delta t'_2$	0
T2	1	1	1	Δt_3	$\Delta t'_3$	$\Delta t'_3$
T3	1	1	1	Δt_4	$\Delta t'_4$	$\Delta t''$
T4	1	0	0	Δt_5	0	0
T5	0	0	0	Δt_6	0	0

Review	Volume transited at flow rate Q_1 (P1 only)	Volume transited at flow rate Q_2 (P2 only)	Volume transited at flow rate $Q_{1.2}$ (P1 and P2 combined)	Total volume transited through the station
Period	'volume[0]' (m^3)	'volume[1]' (m^3)	'volume[2]' (m^3)	'volume[3]' (m^3)
T1	$(\Delta t_1 + \Delta t_2)$. Q1	$(\Delta t'_1 + \Delta t'_2)$. Q_2	0	volume[0] + volume[1] + volume[2]
T2	$(\Delta t_3 + \Delta t'_3)$. Q1	0	$\Delta t'_3$. $Q_{1.2}$	
T3	$(\Delta t_4 + \Delta t'')$. Q1	$(\Delta t'_4 + \Delta t'')$. Q_2	$\Delta t''$. $Q_{1.2}$	
T4	Δt_5Q1	0	0	
T5	Δt_6Q1	0	0	

Configuration

For more information on managing a pump station with flow calculation on two pumps, a .pdf file is available by clicking on "more information about functioning".



Contact selection



The two digital contacts must be different!

Functioning mode

Recording mode

- **Time-stamp pump 1 and 2 starts** : This mode records the date and time of pump 1 and 2 starts.
- **Reporting period** : This mode records the starts count, operating time and volume transited over the defined period for pumps 1 and 2 (individually + operating together).

Sampler enslaving



Pulse generation on pump start, pump operating time or volume transited in the pump station

Pulse output device choice of "Open-drain output" or "Direct external supply" voice (see *Wiring* paragraph)

Specified pump : Pump 1, Pump 2 or any pump.

Operating time is not necessarily continuous: it is accumulated each time the pump is activated.

Pulse duration (ms) : 500 ms by default



Information

- Enter nominal flow rates for pump 1, pump 2 and operating together.

Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.



Mapping table between DataID, channel & data

DataId	Channel	Data displayed	Units	Data Description	Data files
0	0	State	-	Pump 1 status (0 : off / 1 : running / -1 : unchanged status)	*_pump1.bin, *_pumpDiag.bin
0	1	State	-	Pump 2 status (0 : off / 1 : running / -1 : unchanged status)	*_pump2.bin, *_pumpDiag.bin
3	7	Debug (signed integer value)	mAh	Internal battery current consumption	*_diag.bin
6	0	Voltage	V	Instantaneous internal battery voltage (Res. 0.05 V)	*_diag.bin
6	1	Voltage	V	Minimum internal battery voltage reached (Res. 0.05 V)	*_diag.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
17	0	GSM signal Power	dBm	GSM signal power	*_diag.bin
19	0	Date	-	POSIX time	Asynchronous data
22	0	Counter	-	Number of starts of pump 1 for the defined period	*_pumpReport.bin
22	1	Counter	-	Number of starts of pump 2 for the defined period	*_pumpReport.bin
22	2	Counter	-	Number of times pumps 1 and 2 operated together during the defined period	*_pumpReport.bin
39	0	Volume	m³	Volume that has passed through pump 1 only for the defined period	*_pumpReport.bin
39	1	Volume	m³	Volume that has passed through pump 2 only for the defined period	*_pumpReport.bin
39	2	Volume	m³	Volume that has passed through pumps 1 and 2 operating together for the defined period	*_pumpReport.bin
39	3	Volume	m³	Volume that passed through the station during the defined period	*_pumpReport.bin
40	0	Duration	s	Operating time of pump 1 for the defined period	*_pumpReport.bin
40	1	Duration	s	Operating time of pump 2 for the defined period	*_pumpReport.bin
40	2	Duration	s	Operating time of pump 1 and 2 together for the defined period	*_pumpReport.bin

9.6.20. Flow measurement using a 100 Hz velocity counter

Principle

This configuration is used to record pulses from a flowmeter.

Configuration

Prerequisites: In Avelour, the Wiji connection to the logger must be established (see *Connecting to a logger*).

In the logger configuration window:

- Click to add a measurement and select "100 Hz velocity counter".



100 Hz velocity counter parameters

Counting period

The counting period is the length of time during which the pulses received will be accumulated.

First channel

- Select the counting device. (refer to *Wiring*).
- Click on the **"Reset the counter"** button to reset the pulse counter to 0.
- To save accumulated pulses without resetting, click to display the advanced settings and activate **Infinite index recording**.

Indexing pulses

- Activate the **index pulses** option to convert the pulses sent by the flowmeter into a volume and therefore a flow rate.
  - Enter the **weight** of each pulse, as configured in the flowmeter.
  - Enter the**initial index** reflecting the initial state before the start of measurement.
  - Select the**index unit:** mm, m^3Tonne or Watt.

- Activate **Infinite index recording** to save the total number of indexes counted.
- If the unit is m^3, activate average flow recording, if required.



Flowmeter set to send one pulse each time a volume of 0.01 m³ is measured.

Sampler enslaving

This option is rarely used for drinking water network diagnostics. However, as this functionality is common to all sanitation range loggers, the possibility of slave control of a sampler is presented below.

If the pulses sent by the flowmeter have been converted to a volume, it is possible to control a sampler via the logger's open-drain output. In the example below, the logger sends a pulse to the sampler each time it calculates that a volume of 1 cubic meter has passed through the flowmeter.

Example: the logger is in standby mode between two measurements. This means that if the measurement period is 15 minutes, no pulses will be sent to the sampler between two periods. For example, if the logger has received 1000 pulses from the flowmeter over 15 minutes (i.e. 10 cubic meters according to the above example), then 10 pulses in a row will be sent to the sampler after 15 minutes.



Check the wiring between the logger and the sampler

- Click the button to send a single pulse to the sampler to verify that the wiring between the logger and the sampler is correct.

Flow calculation

It is possible to calculate an **hourly flow rate** from pulse data sent by the flowmeter.

If an hourly flow rate is calculated, then it is possible to perform calculations on this hourly volume. In particular, you can activate calculate average flow, minimum flow and/or maximum flow over a given period.



Fifo Memory (Advanced Setting)

By default, when the logger memory is full, data are deleted in chronological order of recording, from oldest to newest.

- Click to display advanced settings.
- If Fifo memory is disabled, change the maximum number of timestamps for the main memory (used for sending data via Internet) and the auxiliary memory (used for sending data via SMS) if necessary.



Configuration summary

To view the configuration summary:

- Click SEE OVERVIEW to display a summary of the configuration.

Depending on the settings selected, the remaining recording time before the memory is full is shown, as well as an average of the number of text messages sent per day.



Mapping table between DataID, channel & data

The table below shows the correspondence for the two DI meters between the type of data recorded (volume, flow, pressure, etc.) and the number encoded by the Ijinus logger (datatype). As several identical types of data can be recorded, a channel number is also added to the datatype.

DataId	Channel	Data displayed	Units	Data Description	Data files
3	7	Debug (signed integer value)	mAh	Internal battery current consumption	*_diag.bin
6	0	Voltage	V	Instantaneous internal battery voltage (Res. 0.05 V)	*_diag.bin
6	1	Voltage	V	Minimum internal battery voltage reached (Res. 0.05 V)	*_diag.bin
17	0	GSM signal Power	dBm	GSM signal power	*_diag.bin
19	0	Date	-	POSIX time	Asynchronous data
22	0	Counter	-	Counter value of the first channel for the counting period	*_histocnt1.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
22	1	Counter	-	Infinite pulse counter for the first channel	*_cnt1.bin
22	2	Counter	-	Counter value of the second channel for the counting period	*_histocnt2.bin
22	3	Counter	-	Infinite pulse counter for the second channel	*_cnt2.bin
22	6	Counter	-	Time (hour) corresponding to the minimum night hourly flow rate for the first channel	*_Min.bin
22	7	Counter	-	Time (hour) corresponding to the maximum night hourly flow rate for the first channel	*_Max.bin
22	9	Counter	-	Time (hour) corresponding to the minimum night hourly flow rate for the second channel	*_Min-2.bin
22	10	Counter	-	Time (hour) corresponding to the maximum night hourly flow rate for the second channel	*_Max-2.bin
34	0	Flow rate	m³/s	Average flow rate for the first channel for the counting period	*_cnt1.bin
34	1	Flow rate	m³/s	Average flow rate for the second channel for the counting period	*_cnt2.bin
39	4	Volume	m³	Hourly flow for the fist channel	*_index.bin
39	5	Volume	m³	Hourly flow for the second channel	*_index-2.bin
39	6	Volume	m³	Minimum night hourly flow for the first channel	*_Min.bin

DataId	Channel	Data displayed	Units	Data Description	Data files
39	7	Volume	m³	Maximum night hourly flow for the first channel	*_Max.bin
39	8	Volume	m³	Average night hourly flow for the first channel	*_Moy.bin
39	9	Volume	m³	Minimum night hourly flow for the second channel	*_Min-2.bin
39	10	Volume	m³	Maximum night hourly flow for the second channel	*_Max-2.bin
39	11	Volume	m³	Average night hourly flow for the second channel	*_Moy-2.bin
15/39/42/43	0	Material height/ Volume/Weight/ Wattage	mm/m³/t/W	Converted value for the first chan-nel	*_histocnt1.bin
15/39/42/43	1	Material height/ Volume/Weight/ Wattage	mm/m³/t/W	Total converted value for the first channel	*_cnt1.bin
15/39/42/43	2	Material height/ Volume/Weight/ Wattage	mm/m³/t/W	Converted value for the second channel	*_histocnt2.bin
15/39/42/43	3	Material height/ Volume/Weight/ Wattage	mm/m³/t/W	Total converted value for the first channel	*_cnt2.bin

9.7. Configuring the sending data

9.7.1. Technologies used

Different methods of data transmission are possible, such as SMS messages or Internet communication using FTP(s), HTTP(s) or CoAP protocols. For this, several technologies can be used: 2G, 3G, LTE-M, NB-IoT and MQTT(s).

The use of a communication PCB is possible to transmit data over LoRaWAN.



NB-IoT technology does not allow data to be sent by SMS.

A very important factor in data transmission is the quality of the telephone operator's signal at the location where the logger is installed. Depending on how the logger is installed, signal quality may be degraded, for example if the logger is placed in a manhole closed by a metal cover.



The quality of the signal during data transmission has an impact on the logger's battery life. Indeed, the poorer the signal quality, the higher the energy consumption needed for transmission.

9.7.2. Signal quality: Mobile Signal Strength Value

Signal strength (dBm)	Signal quality
+ 49 dBm	Default value that may indicate a network connection problem
- 70 to -80 dBm	Very good quality
- 80 to -90 dBm	Good quality
- 90 to -100 dBm	Average quality
- 100 to - 105 dBm	Poor signal quality
+ 113 dBm	No communication possible

9.7.3. Configuring the modem of the communication card

Prerequisites: A SIM card with a “voice” or SMS message package must be inserted into the holder. See paragraph *the section called “Inserting a SIM card”*parameters.

Before being able to send data by SMS or M2M, you must configure the modem on the communication board.

- In the “Data sending” block, click “EDIT".



-> The data transmission parameter editing window is displayed.



Technology to use

- Choose the technology used.

  This could be 2G, 3G, LTE-M, or NB-IoT technology. For 3G, LTE-M and NB-IoT technologies, you can choose an option where 2G technology will be used as a backup if the selected technology is not available.

The selected technology must be compatible with the SIM card inserted in the logger and with the relay antennas located near the logger.

PIN code

- Enter a value in the field if the SIM card is protected by a PIN code.

Only 3 attempts are possible before the SIM card is blocked.

APN

- If the data is sent in M2M (by FTP (S) or CoAP), configure the APN of the SIM card. Hover the mouse over the question mark to display a list of the APN of some telephone operators.
- If a private APN with password is used, click on the icon at the top right of the application to switch to advanced settings.

-> New options appear including fields, where necessary, to specify the username (PPP User) and the password (PPP Password).

- Activate the parameter to enter values in empty fields.



Priority operator (Multi-operator SIM)

This feature requires a firmware update (22.1 or later). Refer to paragraph *Firmware update* .

This feature can only be used with a multi-operator SIM card.

In the case of a multi-operator SIM card, each time a data transmission occurs, a search for a connection to one of the available networks is launched randomly. If after 60 seconds, the attempt to connect to a network fails due to lack of signal strength, the SIM card then attempts to connect to another available network and therefore consumes electrical power.

To prevent the SIM card from attempting to connect to a network with excessively low signal strength, you can specify a priority operator network by entering its MCC + MDC code. (20820: Bouygues, 20801: Orange, 20810: SFR).

To define the priority operator, preferably the one with the highest signal strength at the measurement point, it is advisable to test the signal strength of all operators to determine which one to use in priority. To do this:

- Apply measurement conditions.
- Activate “Priority operator” and enter the operator code of the network to test. (20820: Bouygues, 20801: Orange, 20810: SFR)
- Click “Program modem”.

- Click “Diagnostic Modem” and view the signal strength value. Refer to paragraph *Signal quality: Mobile Signal Strength Value* parameters.
- Repeat the procedure for all mobile network operators to determine the optimal operator for the measurement site.

Program modem

When the Modem parameters have been configured:

- Click on the button “1: Program modem”.

You must click the “1: Program modem” button to send data to the modem; simply saving the configuration does not allow you to configure the modem.



-> Programming the modem takes a few minutes. When the configuration is complete, a window opens to indicate the result:



-> If the programming did not occur correctly, a window opens to indicate the problem encountered (SIM card absent, incorrect PIN code, etc.)

- Each time a parameter is modified (e.g. change of technology), click on the “1: Program modem” button.

9.7.4. Check network quality: Modem diagnostics

After setting up the Modem, you need to make sure that a communication network is available.

- Click the button “2: Modem diagnostic".



-> the communication PCB boots up and searches for a mobile network signal. A window opens to display the results



"Modem Status" window -

If the result is as shown above, it means that no signal has been located.

- Click the "Launch an immediate diagnostic" button to give the modem more time to detect a network. In less than a minute, a satisfactory result should appear as indicated below:



If after 5 minutes of searching the result is not satisfactory, it means that there is a problem with connecting to the network. Several cases are possible:

Problem	Corrective action
No network is available for the selected technology.	• Select another communication technology if the SIM card allows it, then click on the "1: program modem" button
No network is available for the SIM card operator	• Use a multi-carrier SIM card or a SIM card from another carrier

Problem	Corrective action
No network is available for any technology.	• Place the external antenna connected to the logger in a location where communication is more favorable. For example, if the antenna was placed in a manhole or facility, move it outside.
SIM card is not activated	• Check with the SIM card provider that it has been activated.  Pay attention to the scope of validity of the SIM card. Some SIM cards may be limited to certain countries or continents depending on the subscription purchased.

By using the advanced mode, it is possible to perform continuous signal strength measurements over a longer period of time. This option can be used to set the best position of the antenna before drilling a hole in the manhole to offset the antenna from the metal cover.

9.7.5. Data sending in FTP(s)

- Insert a SIM card (with a data package of at least 5 MB per month) into the holder. See paragraph *Inserting the SIM card*.
- When purchasing a SIM card, ask for the operator's APN and PIN code, if available, as this information will be needed.
- Connect the GSM / GPRS antenna to the connector on top of the logger.
- In Avelour, activate **Data sending via Internet: FTP / CoAP**



- Select the data **transmission cycle**.

By default, the logger is programmed to send data to Ijitrack. In this case, no modification to the existing configuration is required.

- If you do not have an Ijitrack account, please contact our customer service department.

You will be asked to provide the product number on the logger label and the installation address.

- If data is being sent to a server other than Ijitrack, click on the icon in the top right of the screen to go to advanced settings and display the following parameters:



- If necessary, contact the FTP server administrator to obtain the three parameters required to send data to a server:
  - Server name or IP address: "Server"
  - Name of user accessing the server: "Username"
  - Password associated with the user: "Password"
- Click on the **FTP data transmission test** button to check that data transmission is working correctly.



-> If data is transmitted, the following window appears:



- After a few minutes, check that the data has arrived on the Ijitrack account or on a different Ijitrack server.

9.7.6. Data sending in Http(s)

Requires firmware version later than or equal to 22.04.

Configuration

Under “Internet data sending”,

- Activate **Internet data sending** and select the HTTP protocol,



Sending data via HTTPS in ijinus format

- **Request format**: Ijinus, Topkapi, Azure IoT Hub.
  - **Ijinus**: Ijinus is a format that allows interoperability with most systems. It is fairly generic and contains all the information you might need. Moreover, custom values can also be added in the header.
  - **Topkapi**: Specific format for compatibility with Topkapi.
  - **Azure IoT Hub**: Format for compatibility with the Azure platform.
- **Server**: Enter the URL of the target server (without http/https). For ijinus, the server is files.ijitrack.com.
- **Port**: Enter the HTTP listening port on the server side.
- **Secure**: HTTP or HTTPS.
- **Uri** : Enter the url of the http request. Not available for ijinus format with files.ijitrack.com server.
- **User name**: With Ijinus format. If needed. It will be included in the body of the request in the user form. It is useful when sending to Ijinus servers.
- **Authentication token**: Enter the authorization token, if required. Will be included in the request body in the Authorization header.

- **Timeout**: Enter an http request timeout in seconds.
- * **Custom headers***: With the Ijinus format. Enables custom headers.
  - **Key**: Enter the header key to be added.
  - **Value**: Enter its value.

Ijinus format

Format of the request sent via a **POST** for the Ijinus format.

POST_Request		
Header	Authorization	58d97_32fb3
	<Key0>	<Value0>
	<Key1>	<Value1>
	<Key2>	<Value2>
	<Key3>	<Value3>
form-data body	tz	Europe/Paris
	user	ijinusHTTP
	sn	IJA0102-12345678
	crc32	1234ABCDE
	file	data.bin

URL

The url will be in the form: [http|https]://

In the example above the url will be: https://myserver.com/http/upload.

Request header

- Authorization: Authentication token, if required.
- Key0: Custom header 0.
- Key1: Custom header 1.
- Key2: Custom header 2.
- Key3: Custom header 3.

Body

The body is in form-data format.

- **tz**: Enter the timezone configured in the sensor.
- **user**: Enter the user (as defined *above*).
- **sn**: Enter the sensor serial number.
- **filepath**: Enter the file path and its name into the sensor.
- **crc32**: Enter the CRC32 of the file.

- **file**: Enter the file in `application/octet-stream.`.

Topkapi format

For TOPKAPI communication:

- Enter the server name or IP address and the Authentication Token provided by TOPKAPI.
- For sensor configuration in TOPKAPI, refer to TOPKAPI documentation.

Azure IoT HUb format

For preformatted transmission to Azure IoT Hub.

The uri is preconfigured in the right format: /devices/ $id/messages/events?api-version=2021-04-12

Request header:

Header	
Authorization	58d97-32fb3

The body is in the format ''

```
{
    "payload":"base64:sdip<gs5fsd465ggsgs"
}
```

9.7.7. Data sending in MQTT(s)

Principle

MQTT is a client-server messaging protocol using the publish/subscribe architecture.

At the heart of MQTT are MQTT brokers and clients. The Broker is an intermediary between senders and recipients. Its role is to distribute messages to the appropriate recipients. Clients post messages to the broker and other clients subscribe to specific topics to receive messages.

Each message includes a topic and customers subscribe to topics that interest them. The broker maintains a list of subscriptions and uses it to deliver messages to the relevant clients.

A broker can also buffer messages for disconnected clients, ensuring reliable message delivery even under unreliable network conditions. To enable this, MQTT supports three different Quality of Service (QOS) levels for message delivery: 0 (at most once), 1 (at least once), and 2 (exactly once) (HiveMQ).

Message format

The format of MQTT messages is json (JavaScript Object Notation).

Topic: Ijinus/Logger/IJA0102-00001848/DATA/diag QoS: 0 Retained


```
{
  "sn": "IJA0102-00001848",
  "tzMinutesOffset":"+120",
  "tzLabel": "CEST",
  "descriptors": [
    {
      "datatype": 6,
      "channel": 0
    },
    {
      "datatype": 6,
      "channel": 1
    },
    {
      "datatype": 3,
      "channel": 7
    },
    {
      "datatype": 17,
      "channel": 0
    }
  ],
  "records": {
    "2025-04-10T11:45:08Z": {"0": 3.45, "1": 3.35, "2": "221", "3": -73}
  }
}
```


Activation

The logger must be equipped with a modem board with a SIM card.

- In Avelour, activate **Internet data sending**

- Set a transmission cycle.
- Select the **MQTT** protocol.



Configuration

- Enter the **Server** identifiers, **Port**, **Username** and **Password**.



Quality of Service (advanced setting)

The MQTT protocol has a quality of service (or QoS) mechanism, which guarantees the delivery of messages to the client in the event of a failure (e.g., connectivity).

- Click on  to display the advanced setting **Quality of service** and enter a value of 0, 1, or 2.

QoS **0**: Lowest quality. The message is only sent once. In the event of a failure, some messages may not be delivered. This quality may be suitable for sending sensor data where occasional data loss would not significantly impact the overall results.

QoS **1**: Quality level where messages are confirmed and resent if necessary. This level of quality of service is typically used in situations where message loss is unacceptable, but message duplication is tolerable. This is suitable for sending command messages to devices, where a missed command can lead to serious consequences, but duplicate commands do not.

QoS **2**: This level enables "exactly once" delivery, where messages are confirmed and resent until they are received exactly once by the subscriber. Quality of Service level 2 is the highest level of quality of service and is generally used in situations where message loss or duplication is completely unacceptable. With QoS 2, the client and broker use a two-step confirmation process, in which the broker stores the message until it has been received and acknowledged by the subscriber. This level of quality of service is typically used for critical messages such as emergency alerts.

Format Almaviva

In the **Almaviva** format, The option **"Send descriptor"** allows to open a new /DESC channel describing the correspondence between the recorded data tracks and the “Var”.



Topic (advanced setting)

The MQTT messaging model is based on topics and subscriptions. Topics are channels where messages are posted and subscribed to. Topics are hierarchical and can contain multiple levels separated by slashes, like a file path.

- Click on  to display the advanced setting **Topic** and customize the topic format if needed.



9.7.8. Advanced internet connection settings

In advanced mode , the following parameters are displayed:



PPP

PPP : Point to point Protocol -> Internet transmission protocol that enables a connection to be established between two hosts over a point-to-point link.

SNTP

SNTP : Simple network time protocol -> Protocol used to synchronise the clocks of devices on a data network.

- Activate **Snt server** and enter the server address for synchronisation.

Custom DNS server

Alternative DNS server : If necessary, enter the IP address of the custom DNS server to add it to the list contained on the SIM card.

Prioritise the alternative DNS server : Must be enabled to allow priority use of custom DNS.

9.7.9. Certificate management

Generalities

A digital certificate or public key certificate is used primarily to identify and authenticate a natural or legal person, but also to encrypt communications. It can be compared to a digital identity card.

A digital certificate is a data file that associates a publicly known cryptographic key with an organization.

Electronic certificates are verified using a chain of trust. The anchor point of this chain is the *root certification authority*.



Root certificate

A root certificate, often referred to as a CA certificate, is a digital certificate that serves as the basis for a public key infrastructure (PKI) system. It is issued by a trusted certification authority (CA) and is self-signed, meaning that the CA authenticates itself. Root certificates are stored in a trusted repository known as a root store, which is maintained by browsers and operating systems to authenticate secure connections.

Intermediate certificate

The intermediate certificate serves as a bridge between the root certificate and server certificates, such as TLS certificates for websites. Unlike root certificates, intermediate certificates are not self-signed; they are signed by a root certificate or another intermediate certificate. This structure creates a hierarchy known as a chain of trust.

Managing certificate



The Certificate Management feature button is only visible if the protocol is enabled as secure.



Certificate Management

General



The **Accept unauthenticated certificates** feature, i.e., certificates that are not signed by a trusted certification authority, can be useful in development and testing environments.

The **Enable Public Root CA Certificates** feature allows you to authorize only private or public certificates.

mTLS certificates

Mutual TLS (mTLS) is an authentication method that ensures secure communication between both parties in a connection. Unlike the traditional TLS method, which only verifies the identity of the server, mTLS authenticates both the client and the server by exchanging and validating digital certificates.

mTLS ensures that the parties at each end of a network connection are who they claim to be by verifying that they both possess the correct private key. The information contained in their respective TLS certificates provides additional verification.

1. The client connects to the server
2. The server presents its TLS certificate
3. The client verifies the server certificate
4. The client presents its TLS certificate
5. The server verifies the client's certificate
6. The server grants access
7. The client and server exchange information via an encrypted TLS connection



CSR certificate and client certificate

To obtain a client certificate, a certificate signing request (CSR) must be made to a CA in order to obtain a client digital identity certificate.

- Fill in the CSR fields and export the request.
- Upload the client certificate (.pem or .ce)

9.7.10. Data sending via SMS

To configure SMS data transmission:

- Click on "EDIT" in the "Data sending" block.



- Activate "SMS data sending".

The **Sending period** corresponds to the frequency at which data are transmitted.

In the example below, transmission occurs every 12 hours:



To check that SMS messages have been sent correctly:

- Enter a phone number in the **Send a test SMS** field indicating the country code (+33 for France).
- Then click on the **Send a test SMS** button and check that the SMS has arrived on the phone identified.



Example of an SMS received on the recipient's phone

- Enter the **server phone** number to transmit the data.

The **SMS Site ID** is a value that identifies the logger on the server and the supervision system used to display the data.

- If data are sent to the Ijitrack web service, no modification is required.
- If data are sent to another supervision system, contact the person in charge of supervision to define the correct SMS Site ID.

9.7.11. Data sending in LoRaWAN

The configuration of data transmission in LoRaWAN is available from version 7.1.2 of the Avelour software.

A logger equipped with an built-in modem has a unique identifier (DevUID). This identifier is required to configure your LoRaWAN server (LNS: Lora Network Server).



Transmission cycle

- Select the frequency of the data transmission cycle on the LoRaWAN server.

Login information

DevEUI: Identity of the end device (64 bits).

AppEUI: Identity of the application (makes the owner of the end device unique).

AppKey: Key used by the server and the end device to encrypt and decrypt packet data.

DevAddr: Identity of the end device (32 bits).

Test data transmission

- Click “Send information message” to send a message containing diagnostic information
- Click “Send data message” to send a message containing measurement data.

Advanced settings



Downlink waiting time

Waiting time between the end of message transmission and the start of the LNS downlink frame listening phase (for TTN: 5000 ms)

Timeout

Maximum network connection time (ms).

Request for acknowledgement

For all transmissions, activate the request for acknowledgement from the LNS.

> Depending on the platform, this may be a paid option.

Multiple send

If there is no acknowledgement, data can be sent multiple times to increase the reception rate.

Expert mode

Reset period

Modem reset periods to ensure that the modem is working. Forces the modem to disconnect from and reconnect to the network.

Use an external antenna

On: External antenna

Off: Internal antenna

Integration of a logger on Orange Live objects

- Select the “Generic_classA_RX2SF12” profile.
- Copy and paste the identifier (DevEUI) and the keys (AppKey and AppEUI) from the data provided in Avelour.



Integration of a logger on WIOTYS

- Select the “LorawanPrivate” protocol
- Copy and paste the identifier (DevEUI) and the keys (AppKey and AppEUI) from the data provided in Avelour.



Integration of a logger on THE THINGS

- Select “Enter end device specifics manually”
- Fill in the Frequency plan, LoRaWAN version and Regional Parameters fields as shown below:



- Copy and paste the identifier (DevEUI) and the keys (AppKey (= JoinEUI) and AppEUI) from the data provided in Avelour.



9.7.12. Configure an alarm

To avoid draining the internal battery too quickly in the event of a programming error, a safety feature can be configured: " alarm parameter ". By default, this parameter imposes a minimum duration of 2 hours between two transmissions related to an alert.

- In the "data sending" window,



- Enter a minimum time between two transmissions.

9.7.13. Sending an alert SMS

The server phone number needs to be configured.

The SIM card must allow sending of SMS text messages.

Sending an alert SMS only works if a threshold is exceeded and Anticipate data sending is active.

- Enter a phone number in the “Send alert SMS” window.

-> A second input field appears, allowing you to add another operator and each time a field is filled another field appears.

It is possible to add up to a maximum of 9 phone numbers.



If data is sent using FTP, approximately 3 minutes elapses between the time that the threshold is exceeded and the message is received.

9.8. Test data transmission before commissioning

9.8.1. Objective

Before commissioning an Ijinus datalogger equipped with a communication PCB, you must ensure it operates correctly in the field with the selected communication networks.

9.8.2. Test procedure

1. In the data transmission menu, click on the edit button, when the popup opens click on the wrench in the top right to display the advanced settings.
2. Configure the modem part as shown below:



   - Select “LTEM” technology only.
   - Set the location to **world**.
   - Enter the **APN** linked to your SIM card.
   - Activate the priority operator: the space to enter the code is now available (you will need to know the operator code beforehand — see the list of operators in the country).
3. Program the modem. 

4. Run modem diagnostics .
5. Activate data sending by Internet with the desired transmission cycle.
6. Start a data transmission test.

9.8.3. Troubleshooting

Network connection issues can occur at key stages of the test:

Problem	Step	Corrective action
Failed to connect to the network	4	• Change the priority operator and redo from step 3 on existing networks

		• Increase timeout from 120 s to 180 s (see image below) 
Failed to connect to SNTP server	6	• Check the APN code
		• Change the priority operator and try again
Connected to the SNTP server but failed to connect to the FTP	6	• Check the FTP server identifiers

9.9. Power supply configuration

The power supply is managed in the "System options" window.



9.9.1. Lithium battery

The logger retrieves the voltage from the external power supply and stops measurements if a minimum voltage threshold is reached. This threshold depends on the type of external power supply and the rated voltage

Examples of thresholds:

- 10.8 V Lithium battery pack: 10.8 x 0.8 = 8.6 V.

To configure a 14.4-volt battery pack:

- In expert mode and advanced settings , change the rated voltage from 10.8 to 14.4 V. The threshold for stopping measurements will be 14.4 x 0.8 = 11.5 V.





Connector power supply: Select whether the probe is powered directly from the external battery or from the logger's internal power supply, in which case the **voltage applied to the output** can be set between 5 and 18 Volts.

Record external power supply voltage: Enables remote monitoring of pack charge.

You must connect to the logger so that it can take measurements with the external sensor connected.

9.9.2. Lead-acid battery

The logger collects the voltage data from the external power supply and stops measurements if a minimum voltage threshold is reached. This threshold depends on the type of external power supply and the rated voltage.

Examples of thresholds:

- 12 V lead-acid battery: 12 x 0.875 = 10.5 V.

For a lead-acid battery and if the logger has been configured with a lead-acid battery, you do not need to connect to the logger via Avelour.

To configure a 12-volt battery pack:

- In expert mode and advanced settings change the nominal voltage to 10.5 V



- Reconnect a recharged battery and the logger will resume its operating cycle.



Connector power supply: Select whether the probe is powered directly from the external battery or from the logger's internal power supply, in which case the **voltage applied to the output** can be set between 5 and 18 Volts.

Record external power supply voltage: Enables remote monitoring of pack charge.

9.10. Set time zone

In the "System Options" window:

- Click on the drop-down menu to select the desired time zone (Europe in the example below).
- Select the city corresponding to the desired time zone.

-> The time that will be applied to the logger is then recalculated automatically.



9.11. Pairing one or more loggers

In addition to its measurement capability, a logger can also be used as a hub (or master logger). In fact, it can retrieve data from another logger wirelessly and by radio, if they are less than 25 m apart in an unobstructed open field, or if one is in a manhole, under a metal cover and the other is not (in this case, the distance between the two hubs must be less than 5 m). The "master" logger then retrieves data from a "slave" logger. This option is called pairing and is configured in the "master" logger. No settings are required on the slave logger.

In the "Retrieve devices" block:

- Click "EDIT".



- Select one or more loggers from the list.

  -> the software generates an **smsid** to identify data from each paired logger when sent by SMS.

The channel number used by some supervision systems to associate equipment data is 0 by default (i.e. cannot be modified via software) for a "master" logger. The channel numbers of paired loggers are set by the "sms id" (here, for example, 1). Each paired sensor will therefore have a different sms id.



- If the sensor you are looking for is not available, click the "refresh" button to update the page.

9.12. Check the status of data recording and transmission

In the configuration window, two icons allow you to control the status of data recording and transmission.

A : Current status

B : Status after loading the configuration on the logger, useful information to check if the configuration being edited is correctly configured.



 No data are being recorded

 No data are being transmitted

 Data are being recorded

 Data are being transmitted

9.13. Save the configuration to the logger



Prerequisites: The logger is connected to Avelour (see *Connecting to a logger*).

To save all the settings configured on the logger:

- Click “SEND CONFIGURATION”.



-> An update loading window is displayed.



-> Data recording is activated and its status is visible via the icon located at the top right of the configuration window (see paragraph *Check the status of data recording and transmission*).

-> Data transmission is activated and its status is visible via the icon icon located at the top right of the configuration window (see paragraph *Check the status of data recording and transmission*).

9.14. Visualize measured values in real time

To visualize the values measured and received by radio from the Ijinus loggers located nearby:

- In the windows tab, click on “View braodcast measures".



-> A new window is displayed.



The amount of data transmitted over the radio is limited by the size of the (Type-8) frames that can be sent over the radio.

Additional note: The channel number in RF frames is encoded using 3 bits, so it can only take values from 0 to 7. For higher channel numbers, modulo 8 is used.

9.15. Stop a recording in progress

- Click on "Stop sensor" to stop recording measurements.



-> Recording and data transmission are stopped.

- To restart the measurement, click on restart.



9.16. Disconnect from the logger

Disconnection from the logger occurs automatically after a few minutes when no data is transferred.

To force disconnection from a logger in Avelour:

- Click the cross to close the configuration window.

9.17. Managing a configuration

9.17.1. View a configuration file

it is possible to view a configuration file offline.

In the saved data window:

- Double-click the configuration file to display it in the main window.



9.17.2. Archive a file

Archiving allows you to manage how files are displayed in the saved data window.

In the Saved data window:

- Right-click on the configuration file to archive and click "Archive selected elements".

-> The configuration file is no longer visible and a folder containing the archived files, named "_archive_" is created in the logger directory.

Example: `C:\ProgramData\Ijinus\Avelour_Main_7.1.2\SavedSensors\IJA0102-00004708\_archive_`

- To view the archived configuration file, click "Filter elements" and click "View Archived elements"



-> The configuration file appears crossed out.

- To retrieve it from the archive, right-click and click "Unarchive selected elements"

9.17.3. Create a configuration template

- Connect to a logger and open an existing configuration via the Saved data window.
- In the "Edit" menu, select "Save device configuration as template".



- Check the "Configuration to apply by default on a new sensor" option so that the template is applied automatically when connecting a new logger.
- Enter a name and click "OK".

-> An .IJCZ file is created in the following directory: `C:\ProgramData/Ijinus/Avelou_Main_7.xxxxx/userTemplates`.

-> The new template is available in the “Edit” menu.



9.17.4. Apply a configuration template

A configuration template must be created. See *Create a configuration template*.

- Connect to the logger that you wish to apply a template to (see *Connecting to a logger*.
- In the "Edit" menu, click on the template to apply.



Chapter 10. Data management on Avelour

10.1. Retrieving saved data

To retrieve saved data:

- Connect to the logger (see paragraph *Connecting to a logger*).
- Click "Retrieve without deleting" to keep the data in memory in the logger or "Retrieve and delete" to empty the recorder memory.



Or

- In the "Actions" menu, click on retrieve measures.



-> The saved data display window opens.



-> In the saved data window, the data appears in the browser structure.



10.2. Retrieve data from auxiliary memory

The data transmitted in SMS text messages are stored in the auxiliary memory of the device.

Data transmitted via FTP are stored in the main memory.

To retrieve data locally with a logger configured to send data in M2M:

- In the main Actions menu, click on Auxiliary measures (for SMS) > Retrieve measures.



-> In the saved data window, the data retrieved appears in the browser structure.

10.3. Create a new calculated value

From the data retrieved in Avelour, it is possible to create new data values by applying a filter.

- In the saved data window, right-click on the base data for the new calculation.



- In the Edit window, select a **filter type** among the four available:
  - Statistical filter
  - Time offset
  - Apply a conversion table
  - Drift correction





Edit window for a new calculated value - Calculation of the average daily temperature value

- Define contextual parameters based on the type of filter selected.
- Click “Save and show” to display the calculated value.

-> The calculated value appears in the saved data browser structure.



10.4. Data graph

10.4.1. Display tools on Avelour



Used to invert the display of the selected data, the hidden data is displayed and the displayed data is hidden.



Used to display the table of all data below the graph.



Used to copy data to the clipboard so that you can paste it.



Used to clear the graph data.



Used to access the graph display customization window. See *Customize the graph display*



Used to export data in different types (Excel, leme, CSV, etc.) to a directory.



The data label allows you to display/hide it with a click.



Switches between day (light) and night (dark) display mode.



Used to zoom in on the graph: Click and hold to select the area to enlarge.

Used to move the cursor on the graph: click, hold click and move.





Hold down the mouse wheel button to activate grabber mode.



Used to restore the initial display of the graph.



Used to export the graph as a PNG image.

X-axis Zoom cursor.

10.4.2. Show data graph

In the Saved data window:

- Double-click on the data or select multiple data elements, right-click and click "View" to view the data as a graph.



-> The saved data viewing window opens.

10.4.3. Customize the graph display

In the saved data viewing window:

- Click the configuration button Configuration to display the graph display properties editing window.



Graph configuration window

10.4.4. Hide the display of data on the graph

- To hide the display of a data item, click the data label at the top of the graph.



-> The data is no longer displayed on the graph and its label appears grayed out.

- Click the button to invert the display, hide the displayed data and display the hidden data.

10.4.5. Display values in table form

In the saved data viewing window:

- Click the “Show data table” button.

-> Data are displayed below the graph.



Date	H2S Concentration	Measure temperature	Voltage	Voltage [1]	Debug (signed integer value) [7]	GSM signal Power
21/06/2024 14:25:00	0 ppm	22,8 °C				
21/06/2024 14:30:00	0 ppm	22,9 °C				
21/06/2024 14:35:00	0 ppm	23 °C				
21/06/2024 14:40:00	0 ppm	23,1 °C				
21/06/2024 14:45:00	0 ppm	23,2 °C				
21/06/2024 14:50:00	0 ppm	23,2 °C				
21/06/2024 14:55:00	0 ppm	23,3 °C				
21/06/2024 15:00:00	0 ppm	23,3 °C				
21/06/2024 15:05:00	0 ppm	23,4 °C				
21/06/2024 15:10:00	0 ppm	23,4 °C				
21/06/2024 15:15:00	0 ppm	23,4 °C				

1-816 of 816

Data table

10.5. Export retrieved data

Data is retrieved in Avelour, see paragraph *Retrieving saved data*parameters.

- In the data viewing window, click on “Export”.
- Select the export type, the period and the export destination directory.





10.6. Delete data recorded on the logger

To delete data recorded on the logger memories:

- In the "Actions" menu, click "delete measures" to delete the main memory of the logger.

- In the "Actions" menu, click "delete measures" in the sub-menu "Auxiliary measures (for SMS)" to delete the auxiliary memory.

When connecting to a logger, if data is present, it is then possible to retrieve and delete data. The deleted data will then be that of the main memory.



Chapter 11. Maintenance

In the event of a problem with an Ijinus logger or sensor, we recommend that you contact our after-sales department either by e-mail: sav@ijinus.fr or by telephone: +33 (0)298 090 332

You will be informed of the applicable procedure, so that you can either test the product yourself or return it to the factory for testing on our premises.

11.1. Replacing the battery

When the logger's battery is at the end of its life, a red banner appears on Avelour, inviting you to replace the battery.



Avoid leaving the logger open for too long (just a few minutes), because if the desiccant bag absorbs too much moisture, it will no longer be effective and will turn green.

- Unscrew the clamping ring (**A**) and remove the cover.
- Remove the battery and disconnect the circuit board.
- Check the color of the desiccant bags and replace them if they are green.
- Check the seal for damage.
- Check seal lubrication and if necessary, lubricate with neutral grease.
- Replace the cover as far as it will go, taking care to fit the insertion notch into the coded hole (**B**).







-> When the circuit board is restarted, the LED on the front of the board should flash red/green and then, after 2 to 3 minutes, only green every 10 seconds.

- In Avelour, click on "battery changed".

If the battery has been changed before the red banner appears, you must also record the battery change:

- Connect to the logger (see *Connecting to a logger*).
- In the actions menu, click on "report battery change" to restart the logger and return the energy gauge to 0.



-> In the device properties window, the battery gauge changes to 0 mAh.



11.2. Firmware update

A firmware update may be required when updating the Avelour programming software.

- Connect to the logger (see paragraph *Connecting to a logger*).
- In the "Options" menu, click on "Troubleshooting and errors".
- By connecting to the logger in advance, the choice of device (1) is already made. To change this choice, click “Device choice”.
- In the list of actions to launch (2), select “Upgrade the device firmware”.
- Click “Choose firmware”.

-> The Firmware folder opens.



- Select the corresponding .xbin file and click “Launch the action” (3).

11.3. Remote firmware update

The logger must be equipped with a modem card and configured to send data via **FTP**, **HTTP** or **MQTT**.

If you are using the ijitrak server, contact Ijinus to obtain the identifiers and password and configure Avelour.

If using another server, contact Ijinus to obtain a version of Avelour enabling you to customize the server configuration.

Beware ! Remote firmware update and remote configuration can't be done simultaneously. Take care to launch one after the other.

- Hold down the CTRL key and select one or more loggers and right-click.
- Click on “Remote firmware update".



-> The update window opens and displays the firmware serial number(s), status, current version and new version.



- Click “Update".

-> The update file is sent to the FTP server and the update will be performed during the next data transmission.

11.4. Reset the logger (factory settings)

The logger may need to be reset when a service request is made or if the password is forgotten.

The Reset process deletes all configuration files and data stored on the logger.

11.4.1. Wiji reset

- Connect to the logger (see *Connecting to a logger*).
- In the **Options** menu, click on **Diagnostics and errors**.
- Check that the serial number (**1**) corresponds to that of the logger.
- Check **Equipment reset (loss of data and configuration** (**2**).
- Click on **Launch** (**3**).

-> the logger formatting window appears.

Depending on the amount of data to be deleted, the reset process may take a few minutes.



11.4.2. Manual reset

Avoid leaving the logger open for too long (just a few minutes), because if the desiccant bag absorbs too much moisture, it will no longer be effective and will turn green.

Removing the cover can be difficult due to the gasket. The cover antenna is connected to the circuit board, so to avoid pulling out the circuit board when opening the logger, we strongly advise you to open the logger as follows:

- Partially unscrew the clamping ring (approx. 2 turns).
- Pull on the cover until it is partially extracted, blocked by the clamping ring.
- Unscrew the clamping ring completely to fully remove the cover.
- To make it easier to press the buttons, we recommend removing the battery from its housing.
- Press the **SW** (**B**) button, then the **RST** (**A**) button, and release the **RST** button.

  -> The status LED (**C**) flashes red.



- When the LED changes to flashing green, release the **SW** (**B**) button.

  -> Reset starts.

Depending on the amount of data to be deleted, the reset process may take a few minutes.

The LED resumes its initial flashing cycle (every 10 seconds in green) as soon as the reset is complete.

11.5. Replacing the cartridge on a PHEHET sensor

- To avoid damaging the sensor's electronic components, hold the cartridge in one hand and unscrew the clamping ring with the other hand.
- Remove the used cartridge and fit the new one before screwing the clamping ring back on.

PHEHT cartridge P/N : F0A00003

11.6. Cleaning

11.6.1. OPTOD sensor

After each use:

- rinse meticulously the sensor and the membrane with clear water.
- If deposits like biofilm or mud persist, wipe the membrane gently with a sweet cloth or an absorbent paper.

- 

  Warning : for the Titanium version clean the sensor body with acetone (do not use alcohol, ethanol or methanol).

  Warning : Only unscrew the strainer containing the DODISK in case of change. If replacing the strainer, replace the new one and screw back slowly so the air can escape slowly.

11.6.2. NTU sensor

- After each use, rinse meticulously the sensor with clear water.
- If deposits like biofilm or mud persist, clean the sensor with soapy water and wipe the head with a soft cloth or an absorbent paper.

11.6.3. PHEHT sensor

After each use, rinse meticulously the sensor with clear water.

pH: If deposits like biofilm or mud persist, put the sensor in a cleaning solution (H0Y00012) for a few hours and rinse profusely before use.

Avoid using a soft cloth or an absorbent paper because the glass ball is extremely vulnerable to frictions.

Redox: clean the platinum disk with an abrasive moist paper (type P1200 or P220)

11.6.4. Redox annulaire

- After each use, rinse the sensor thoroughly with clean water. Clean the platinum ring using fine, damp sandpaper (such as P1200 or P220).

11.6.5. C4E sensor

After each use, rinse meticulously the sensor with clear water. If deposits like biofilm or mud are still in the measuring gap or on the electrodes, use a moist abrasive paper to clean off the surface of electrodes.

11.6.6. CTZ sensor

After each use, rinse the sensor thoroughly with clean water.

Chapter 12. Storage

12.1. Sensor Storage

12.1.1. OPTOD sensor

Temperature of storage: - 10°C to + 60°C

- Keep the membrane hydrated with the protective case and a moist absorbent surface (like cotton).
- After dry storage, rehydrate the membrane for a 12 hours period.

12.1.2. PHEHT sensor

Temperature of storage: - 10°C to + 60°C

- Maintain the glass membrane **hydrated in the protection case with a few drops of preservation agent solution** or, if it is not available, with the solution of pH4. Rinse profusely the bulb of glass before use.
- After storage in dry environment, put the sensor in a standard solution PH4 for 12 hours.
- The case protects against direct impact on the head of the sensor. The platinum electrode is preserved dry.

12.1.3. Redox annulaire sensor

Temperature of storage: 0°C to + 60°C

- Keep the sensor head moist using the protective case containing a few drops of preservative solution or a KCl solution.
- Rinse the sensor head thoroughly before use.
- After dry storage, place the probe in a KCl solution for 12 hours. The protective case absorbs direct impacts to the sensor head.

12.1.4. NTU sensor

Temperature of storage: - 10°C to + 60°C

- Put the protection case on the head of the sensor to protect the optical part.

12.1.5. C4E sensor

Temperature of storage: 0°C to + 60°C

The case protects against direct impact on the head of the sensor. The platinum electrode is preserved dry.

For short-term storage, place a cotton wool pad at the bottom of the case with a few drops of buffer solution at 1413 µS/cm.

12.1.6. CTZ sensor

Temperature of storage: - 10°C to + 60°C

The sensor is kept dry.